

NK Series

Compact Routers

User Guide



Video Production Technology

NK Series - User Guide

- Ross Part Number: **9807DR-0100-03**
- Release Date: December 12, 2012.

The information contained in this Guide is subject to change without notice or obligation.

Copyright

© **2012 Ross Video Limited**. All rights reserved.

Contents of this publication may not be reproduced in any form without the written permission of Ross Video Limited. Reproduction or reverse engineering of copyrighted software is prohibited.


Patents

This product is protected by the following US Patents: 4,205,346; 5,115,314; 5,280,346; 5,561,404; 7,034,886; 7,508,455; 7,602,446; 7,834,886; 7,914,332. This product is protected by the following Canadian Patents: 2039277; 1237518; 1127289. Other patents pending.

Notice

The material in this manual is furnished for informational use only. It is subject to change without notice and should not be construed as commitment by Ross Video Limited. Ross Video Limited assumes no responsibility or liability for errors or inaccuracies that may appear in this manual.

Trademarks

-  is a registered trademark of Ross Video Limited.
- Ross, ROSS, and ROSS®, are registered trademarks of Ross Video Limited.
- Microsoft, Encarta, MSN, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- All other product names and any registered and unregistered trademarks mentioned in this guide are used for identification purposes only and remain the exclusive property of their respective owners.

Important Regulatory and Safety Notices to Service Personnel

Before using this product and any associated equipment, read all the Important Safety Instructions listed below so as to avoid personal injury and to prevent product damage.

Symbol Meanings



Protective Earth — This symbol identifies a Protective Earth (PE) terminal, which is provided for connection of the supply system's protective earth (green or green/yellow) conductor.



This symbol on the equipment refers you to important operating and maintenance (servicing) instructions within the Product Manual Documentation. Failure to heed this information may present a major risk of damage or injury to persons or equipment.



Warning — The symbol with the word “**Warning**” within the equipment manual indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Caution — The symbol with the word “**Caution**” within the equipment manual indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



Warning Hazardous Voltages — This symbol is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product enclosure that may be of sufficient magnitude to constitute a risk of shock to persons.



ESD Susceptibility — This symbol is used to alert the user that an electrical or electronic device or assembly is susceptible to damage from an ESD event.

Important Safety Instructions

Read these instructions and heed all warnings.



Warning The safe operation of this product requires that a protective earth connection be provided. A grounding conductor in the equipment's supply cord provides this protective earth. To reduce the risk of electrical shock to the operator and service personnel, this ground conductor must be connected to an earthed ground.

Use only power cords specified for this product and certified for the country of use. Refer to the Product Power Cord Requirement Section that follows.

Do not defeat safety purpose of the grounding-type plug. A grounding type plug has two blades and a third grounding prong. The third prong is provided for your safety. If the provided plug does not fit in to your outlet, consult an electrician for replacement of the obsolete outlet.

Protect the power cord from being walked on or pinching particularly at plugs, convenience receptacles, and point where they exit from the apparatus.



Warning Indoor Use: “WARNING – TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE”

Do not block any ventilation openings. Install in accordance with manufacturer's instructions.

Only use attachments/accessories specified by the manufacturer.

**Warning**

Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug damage, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

**Caution**

To reduce the risk of fire, replacement fuses must be the same type and rating.

**Warning**

This product contains safety critical parts, which if incorrectly replaced may present a risk of fire or electrical shock. Components contained within the product's power supplies and power supply area, are not intended to be customer serviced and should be returned to the factory for repair

Product Power Cord Requirements**Warning North American Line Voltages 100 - 120 Volt**

This product is supplied with certified 10A/125V SVT type supply cords.

Conductors are color coded white (neutral), black (line) and green or green/yellow (ground).

Operation of this equipment at line voltages exceeding 130V requires that alternative supply cords with appropriate voltage and current ratings be used.

Warning International Line Voltages 200 - 240 Volt

This product has been designed for use with certified IEC 320- C13 10A/250V - H03 VV-F3G 1.00mm² type line cord.

International product orders are supplied with a certified 10A/250V line cords, utilizing a molded 3-pin IEC 320-C13 type connector at one end and stripped conductors on the other. One line cord is provided. Conductors are CEE color coded; blue (neutral), brown (line), and green/yellow (ground).

Installation by a qualified Electrician, of an appropriately approved A/C wall plug certified for the country of use, is required.

Alternatively, other IEC 320 C-13 type power cords may be used, provided that they meet the necessary safety certification requirements for the country in which they are to be used. Refer to the correctly specified line cord above.

EMC Notices**US FCC Part 15**

This equipment has been tested and found to comply with the limits for a class A Digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a Commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



Notice — *Changes or modifications to this equipment not expressly approved by Ross Video Ltd. could void the user's authority to operate this equipment.*

CANADA

This Class "A" digital apparatus complies with Canadian **ICES-003**.

Cet appareil numérique de la classe "A" est conforme a la norme **NMB-003** du Canada.

EUROPE

This equipment is in compliance with the essential requirements and other relevant provisions of **CE Directive 93/68/EEC**.

INTERNATIONAL

This equipment has been tested to **CISPR 22:1997** along with amendments **A1:2000** and **A2:2002** and found to comply with the limits for a Class A Digital device.



Notice — *This is a Class A product. In domestic environments, this product may cause radio interference, in which case the user may have to take adequate measures.*

CE/C-tick approval

The equipment meets the requirements of the Australian Communications and Media Authority (Limits & Methods Of Measurement Of Radio Interference Characteristics Of Information Technology Equipment (EN55022/CISPR 22)).

Warranty and Repair Policy

The product is backed by a comprehensive one-year warranty on all components.



Notice — *Changes or modifications to this equipment not expressly approved by Ross Video Limited could void the user's authority to operate this equipment.*

If an item becomes defective within the warranty period Ross will repair or replace the defective item, as determined solely by Ross.

Warranty repairs will be conducted at Ross, with all shipping FOB Ross dock. If repairs are conducted at the customer site, reasonable out-of-pocket charges will apply. At the discretion of Ross, and on a temporary loan basis, plug in circuit boards or other replacement parts may be supplied free of charge while defective items undergo repair. Return packing, shipping, and special handling costs are the responsibility of the customer.

This warranty is void if products are subjected to misuse, neglect, accident, improper installation or application, or unauthorized modification.

In no event shall Ross Video Limited be liable for direct, indirect, special, incidental, or consequential damages (including loss of profit). Implied warranties, including that of merchantability and fitness for a particular purpose, are expressly limited to the duration of this warranty.

This warranty is TRANSFERABLE to subsequent owners, subject to Ross' notification of change of ownership.

Extended Warranty


For customers that require a longer warranty period, Ross offers an extended warranty plan to extend the standard warranty period by one year increments. For more information, contact your regional sales manager.

Environmental Information

The equipment that you purchased required the extraction and use of natural resources for its production. It may contain hazardous substances that could impact health and the environment.

To avoid the potential release of those substances into the environment and to diminish the need for the extraction of natural resources, Ross Video encourages you to use the appropriate take-back systems. These systems will reuse or recycle most of the materials from your end-of-life equipment in an environmentally friendly and health conscious manner.

The crossed-out wheeled bin symbol invites you to use these systems.



If you need more information on the collection, reuse, and recycling systems, please contact your local or regional waste administration.

You can also contact Ross Video for more information on the environmental performances of our products.

Company Address



Ross Video Limited

8 John Street
Iroquois, Ontario
Canada, K0E 1K0

Ross Video Incorporated

P.O. Box 880
Ogdensburg, New York
USA 13669-0880

Ross Video Australia

Unit 24, 49 Corporate Boulevard
Bayswater VIC 3153
Australia

General Business Office: (+1) 613 • 652 • 4886

Fax: (+1) 613 • 652 • 4425

Technical Support: (+1) 613 • 652 • 4886

After Hours Emergency: (+1) 613 • 349 • 0006

E-mail for Technical Support: techsupport@rossvideo.com

E-mail for General Information: solutions@rossvideo.com

Website: <http://www.rossvideo.com>

Contents

Introduction	1
Overview of this Guide	1-1
Overview	2
Features	2-1
Installation	3
NK-16, NK-32 and NK-34 Routers	3-1
NK-S Series	3-1
NK-MD Series	3-1
NK-3G Series	3-1
AES/EBU Digital Audio Level	3-3
Analog Video Level	3-5
Stereo Analog Audio Level	3-7
Machine Control / Data Level	3-9
NK-64 and NK-72 Router Formats.....	3-10
NK-S Series	3-10
NK-MD Series	3-10
NK-3G Series	3-10
AES/EBU Digital Audio Level	3-11
Stereo Analog Audio Level	3-12
Control Panels	3-14
RCP-NK1	3-14
RCP-NKM	3-15
RCP-NKQ	3-15
NK-VCP	3-16
NK-VRC	3-17
Interface and Connectivity	3-17
The NK-IPS	3-17
The NK Hub	3-18
The NK-3RD	3-19
The NK-SCP	3-20
The NK-GPI	3-20
The T-Bus Control System	3-21
The Heartbeat	3-21
NK Series Router Power Supplies	3-21
Connecting NK Components	3-22
Unpacking and Pre-Installation	3-22
Connection Overview	3-22
Connecting the NK-SCP	3-24
Connecting the NK-GPI	3-26
Customizing RCP-NK1 Control Panels.....	3-28
Overview	3-28
Localizing the Panel	3-28
Configuration	4
Default Configuration	4-1
Overview	4-1
RCP-NK1 Control Panel Default Configuration	4-1

RCP-NKM/Q Control Panel Default Configuration	4-3
Configuring Routers	4-4
Overview	4-4
Configuration Options — NK-IPS	4-4
Configuration Options — Phoenix	4-9
Configuring the RCP-NK1 Panel	4-13
Overview	4-13
RCP-NK1 Configuration	4-14
Configuring the NK-SCP	4-21
NK-SCP/A Configuration	4-21
NK-SCP/K2 Configuration	4-24
Configuring the GPI	4-27
Configuration Options	4-27

Operation 5

NK Series Operation	5-1
Start-up Process	5-1
Router Start-up	5-1
Control Panel Start-up	5-1
Single Panel RCP-NK1 Operation	5-1
Overview	5-1
Operation Basics	5-2
Linked RCP-NK1 Panel Operation	5-11
Overview	5-11
NK-A64 Control Layer	5-12
Overview	5-12
Control Layer Operation via NK Control Panels	5-13
NK-SCP Operation	5-14
NK-SCP/A Operation Overview	5-14
Using the ASCII Protocol	5-14
NK-SCP/K2 Operation	5-16
Video Referencing	5-17
Overview	5-17
Connecting a Video Reference to NK Routers	5-17

Appendix A: Connectors and Pinouts 6

DB-25 Pinouts for Analog and Digital Audio Routers	6-1
16x16 Routers	6-1
32x32 Routers	6-2
64x64 Routers	6-4
Power Connector - DB-9 (All NK-16 and NK-32 Routers)	6-5
Machine Control DB-9 Pinouts (NK-M16 and NK-M32)	6-6
GPI Alarm (NK-64 & NK-72 Models only)	6-6
T-Bus RJ-45 Connector	6-7
SCP/A DB-9 Pinouts	6-7
SCP/K2 DB-9 Pinouts	6-7

Appendix B: Analog Audio Router I/O Levels 7

Overview	7-1
NK-A16 and NK-A32 Routers (Input)	7-1
NK-A16 and NK-A32 Routers (Output)	7-2
NK-A64 Router (Input)	7-2
NK-A64 Router (Output)	7-3

Appendix C: Multi-Definition Router Format Selection

8

Output Rise Time DIP Switches

8-1

NK-MD164, NK-MD16, and NK-MD34

8-1

NK-MD64 and NK-MD72

8-2

Introduction

Thank you for purchasing the Ross Video NK Series Routing System. With Ross Video's reputation for delivering leading-edge routing switcher equipment and our unsurpassed level of customer service and support, you can look forward to many years of reliable broadcasting. Please read this guide thoroughly and retain it for future reference.

Overview of this Guide

This guide is for system administrators, installers and operators of the Ross Video NK Series Routing System. It provides instructions on how to connect and configure the routing switcher system. It assumes that you are experienced with general broadcast concepts, and that you are familiar with the planning requirements for a routing switcher system.

A separate user manual is available for the following products:

- NK-3G320 Routing Switcher
- NK-3G144 Routing Switcher
- NK-IPS Internet Protocol Server
- NK-VRC Virtual Routing Core
- NK-3RD Third Party Interface
- RCP-NKM Remote Control Panel
- RCP-NKQ Remote Control Panel

Overview

Ross Video's NK Series Routing Systems are a comprehensive family of routing solutions with a wide variety of matrix sizes and types to choose from, several flexible control panels, and a powerful control system tying it all together.

Features

The NK Series of routers are available in a variety of sizes and signal types.



Figure 2.1 16x4 Utility Switchers and 16x16 Routers (1RU)




Figure 2.2 32x32 Routers (2RU)




Figure 2.3 64x64 and 72x72 Routers (3RU)

Matrix Sizes

- Fixed size 16x4 and 16x16 in 1RU
- Fixed size 32x32 and 34x34 in 2RU
- Expandable up to 64x64 and 72x72 in 3RU
- Expandable up to 144x144 in 10RU
- Expandable up to 320x320 in 19RU

Signal Types

- NK-3G Series: 3G/HD/SD
- NK-MD Series: HD/SD
- NK-S Series: SD
- 75 Ohm and 110 Ohm AES/EBU Digital Audio
- Analog Video
- Stereo Analog Audio
- Machine / Data Control (RS422)

Control of the routers can be done using a variety of methods, including:

- 40 Button Remote Control Panel (RCP-NK1)
- 40 Button & LCD Display Remote Control Panel (RCP-NKM)
- 17 LCD Button Remote Control Panel (RCP-NKQ)
- Phoenix Control Surface software for setup and control
- 10/100 Ethernet Interface
- Virtual routing
- Third Party RS422 serial control
- RS232 and GPI/Tally Interface



Figure 2.4 RCP-NKQ Control Panel



Figure 2.5 RCP-NKM Control Panel



Figure 2.6 RCP-NK1 Control Panel

Installation

NK-16, NK-32 and NK-34 Routers

NK-S Series

The SD level of the NK-16 and NK-34 range conforms to SMPTE standard 259M and is available in 16x4 (NK-S164), 16x16 (NK-S16), and 34x34 (NK-S34) sizes.

NK-MD Series

The Multi-Definition (MD) level of the NK-16 and NK-34 range conforms to SMPTE standards 259M, 292M and 344M, and is available in 16x4 (NK-MD164), 16x16 (NK-MD16), and 34x34 (NK-MD34) sizes.

All NK Multi-Definition level routers have a selectable output rise and fall times, via on-board DIP switches; please refer to “**Appendix C: Multi-Definition Router Format Selection**” on page 8–1.

NK-3G Series

The 3G level of the NK-16 and NK-34 range conforms to SMPTE standards 259M-C, 292M, 424M, and DVB-ASI, and is available in 16x4 (NK-3G164), 16x16 (NK-3G16), and 34x34 (NK-3G34).




Figure 3.1 NK-S164, NK-MD164, & NK-3G164 – 16x4 Rear IO




Figure 3.2 NK-S16, NK-MD16, & NK-3G16 – 16x16 Rear IO




Figure 3.3 NK-S34, NK-MD34, & NK-3G34 – 34x34 Rear IO

Specifications

Table 3.1 Inputs

	SD	MD	3G
Connection	75 Ω BNC	75 Ω BNC	75 Ω BNC
Return Loss	> 22 dB	> 17 dB	> 15 dB 5 MHz to 15 GHz > 10 dB 1.5 GHz to 3.0 GHz
Cable EQ	Up to 350 m Belden 8281	Up to 100 m Belden 8281	Up to 80 m Belden 1694

Table 3.2 Outputs

	SD	MD	3G
Connection	75 Ω BNC	75 Ω BNC	75 Ω BNC
Clocking	Non-reclocking	Non-reclocking	Reclocking on all outputs automatic at SMPTE 259M-C, 292M, 424M, and DVB-ASI
Return Loss	> 22 dB	15 dB	15 dB 5 MHz to 15 GHz 10 dB 1.5 GHz to 3.0 GHz
Level	800 mV p-p	800 mV p-p	800 mV p-p

Table 3.3 Performance

	SD	MD	3G
Jitter	< 370 ps (.09 UI)	< 0.2 UI	< 0.2 UI to 1.5 GHz < 0.3 UI to 3.0 GHz
Data Rates	143 Mb/s to 540 Mb/s	143 Mb/s to 1.485 Gb/s	143 Mb/s to 2.97 Gb/s
Overshoot	< 10 %	< 10 %	< 10 %
Rise/Fall Time	700 ps (typical)	Selectable SD/HD rise time via on-board DIP switches. 700 ps (typical SD) 120 ps (typical HD)	Automatic at SMPTE 259M-C, 292M, 424M, and DVB-ASI

Table 3.4 General

	SD	MD	3G
Partitioning	Up to 8 partitions with independent level assignment	Up to 8 partitions with independent level assignment	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS	Phoenix or web browser via NK-IPS	Phoenix or web browser via NK-IPS
Dimensions	1 RU x 64 mm deep (NK-S164 and NK-S16) 2 RU x 64 mm deep (NK-S34)	1 RU x 64 mm deep (NK-MD164 and NK-MD16) 2 RU x 64 mm deep (NK-MD34)	1 RU x 64 mm deep (NK-3G164 and NK-3G16) 2 RU x 64 mm deep (NK-3G34)
Power Consumption	10.5 W (NK-S164 and NK-S16) 30 W (NK-S34)	10.5 W (NK-MD164 and NK-MD16) 30 W (NK-MD34)	8.5 W (NK-3G164) 13 W (NK-3G16) 27 W (NK-3G34)
Power Supply	+15 V DC	+15 V DC	+15 V DC

Specifications are subject to change without prior notice.

AES/EBU Digital Audio Level

The AES/EBU level of the NK-16 and NK-32 range conforms to AES/EBU standards for digital audio. It is available in 16x4 (NK-D164), 16x16 (NK-D16), and 32x32 (NK-D32) sizes.

NK-D16, NK-D164 and NK-D32 models are available in 75 Ω BNC models or 110 Ω DB-25 models.




Figure 3.4 NK-D164/75 – 75 Ω , 16x4 Rear IO




Figure 3.5 NK-D164 /110 – 110 Ω , 16x4 Rear IO




Figure 3.6 NK-D16/75 – 75 Ω , 16x16 Rear IO




Figure 3.7 NK-D16/110 – 110 Ω , 16x16 Rear IO




Figure 3.8 NK-D32/75 – 75 Ω , 32x32 Rear IO




Figure 3.9 NK-D32/110 – 110 Ω , 32x32 Rear IO

Specifications

Table 3.5 Inputs

Connection	75 Ω BNC (D16/75 and D32/75) 110 Ω DB-25 connectors (D16/110 and D32/110)
Level	1 V p-p (75 Ω) 2-7 V p-p (110 Ω)
Cable EQ	Up to 300 m RG59/U

Table 3.6 Outputs

Connection	75 Ω BNC (D16/75 and D32/75) 110 Ω DB-25 connectors (D16/110 and D32/110)
Clocking	Non-reclocking
Level	1 V p-p (75 Ω) 3-4 V p-p (110 Ω)

Table 3.7 Performance

Jitter	< 2 ns (.013 UI)
Data Rates	32 kHz to 192 kHz

Table 3.8 General

Partitioning	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS
Dimensions	1 RU x 64 mm deep (NK-D16 and NK-D164) 2 RU x 64 mm deep (NK-D32)
Power Consumption	7.5 W (NK-D16 and NK-D164) 10.5 W (NK-D32)
Power Supply	+15 V DC

Specifications are subject to change without prior notice.

Analog Video Level

The Analog Video level of the NK-16 and NK-32 range is a wide bandwidth, high performance router available in 16x4 (NK-V164-HQ), 16x16 (NK-V16-HQ), and 32x32 (NK-V32-HQ) sizes.




Figure 3.10 NK-V164-HQ – 16x4 Rear IO




Figure 3.11 NK-V16-HQ – 16x16 Rear IO




Figure 3.12 NK-V32-HQ – 32x32 Rear IO

Specifications

Table 3.9 Inputs

Connection	75 Ω BNC
Nominal Input Level	1 V p-p
Maximum Input Level	2 V p-p
Clamping Method	AC coupled with sync tip Clamping
Clamping DC Adjustment	Between blanking = 0 V and sync tip = 0 V
Return Loss	44 dB

Table 3.10 Outputs

Connection	75 Ω BNC
Level	1 V p-p
Coupling	DC coupled
Return Loss	30 dB

Table 3.11 Performance

Differential Gain	0.05 deg
Differential Phase	0.05 deg
Frequency Response	30 MHz, ± 0.1 dB 60 Mhz, ± 1 dB 230 Mhz, -3 dB
Noise	-76 dB peak
Crosstalk	-60 dB, 5 MHz
Propagation Delay	2 ns
Timing Scatter	0.5 deg fsc

Table 3.12 General

Partitioning	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS
Dimensions	1 RU x 64 mm deep (NK-V16-HQ and NK-V164-HQ) 2 RU x 64 mm deep (NK-V32-HQ)
Power Consumption	8 W (NK-V16-HQ and NK-V164-HQ) 20 W (NK-V32-HQ)
Power Supply	+/-15 V DC

Specifications are subject to change without prior notice.

Stereo Analog Audio Level

The Stereo Analog Audio level of the NK-16 and NK-32 range is a wide bandwidth, high performance router, available in 16x4 (NK-A164-HQ), 16x16 (NK-A16-HQ), and 32x32 (NK-A32-HQ) sizes.

All Analog Audio level routers have selectable +4 / -10 dBu input and output levels, via on-board solder links, please refer to “**Appendix B: Analog Audio Router I/O Levels**” on page 7–1.




Figure 3.13 NK-A164-HQ – 16x4 Rear IO




Figure 3.14 NK-V16-HQ – 16x16 Rear IO




Figure 3.15 NK-A32-HQ – 32x32 Rear IO

Specifications

Table 3.13 Inputs

Connection	DB-25 Female on chassis (8 audio channels)
Connection Type	Balanced active differential
Input Z	24 K Ω
Nominal Input Level	+4 dBu or -10 dBu (selectable via solder links)
Maximum Input Level	+24 dBu
CMRR	60 dB

Table 3.14 Outputs

Connection	DB-25 Female on chassis (8 audio channels)
Connection Type	Balanced active differential
Output Z	50 Ω differential
Nominal Output Level	+4 dBu or -10 dBu (selectable via solder links)
Maximum Output Level	+24 dBu

Table 3.15 Performance

Frequency Response	± 0.1 dB, 20 Hz to 20 kHz -3 dB, 100 kHz	
Distortion	.005 %	
Noise	-90 dB below +4 dBu	
Crosstalk	-86 dB below +4 dBu	Below noise



Table 3.16 General

Partitioning	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS
Dimensions	1 RU x 64 mm deep (NK-A16-HQ and NK-A164-HQ) 2 RU x 64 mm deep (NK-A32-HQ)
Power Consumption	13.5 W (NK-A16-HQ and NK-A164-HQ) 33 W (NK-A32-HQ)
Power Supply	±15 V DC

Specifications are subject to change without prior notice.

Machine Control / Data Level

The Machine Control level of the NK-16 and NK-32 range is capable of routing RS-422 signals for reciprocal switches. It is available both 16x16 (NK-M16), and 32x32 (NK-M32) models.

**Figure 3.16 NK-M16 – 16x16 Rear IO****Figure 3.17 NK-M32 – 32x32 Rear IO**

Specifications

Table 3.17 Inputs

Connection	DB-9 Female on chassis
Electrical Standard	RS-422
Direction	Auto port direction switching

Table 3.18 Performance

Data Rates	Up to 115.2 kBd
------------	-----------------

Table 3.19 General

Configuration	Phoenix or web browser via NK-IPS
Dimensions	1RU x 64 mm deep (NK-M16) 2RU x 64 mm deep (NK-M32)
Power Consumption	10.5 W (NK-M16) 18 W (NK-M32)
Power Supply	+15 V DC

Specifications are subject to change without prior notice.

NK-64 and NK-72 Router Formats

NK-S Series

The SD level conforms to SMPTE standard 259M.

NK-MD Series

The Multi-Definition (MD) level conforms to SMPTE standards 259M, 292M and 344M.

All NK Multi-Definition level routers have a selectable output rise and fall times, via on-board DIP switches; please refer to “**Appendix C: Multi-Definition Router Format Selection**” on page 8–1.

NK-3G Series

The 3G level of the NK-64 and NK-72 support SMPTE standards 259M-C, 292M, 424M, and DVB-ASI, with output reclocking. The input EQ and reclocker are bypassable through the control system. The output slew rates are automatically set.




Figure 3.18 NK-S72, NK-MD72, & NK-3G72 – 72x72 Rear IO

Specifications

Table 3.20 Inputs

	SD	MD	3G
Connection	75 Ω BNC	75 Ω BNC	75 Ω BNC
Return Loss	>22 dB	> 17 dB	> 17 dB
Cable EQ	Up to 350 m Belden 8281	Up to 100 m Belden 8281	Up to 100 m Belden 8281

Table 3.21 Outputs

	SD	MD	3G
Connection	75 Ω BNC	75 Ω BNC	75 Ω BNC
Clocking	Non-reclocking	Non-reclocking	Reclocking
Return Loss	>22 dB	15 dB	15 dB
Level	800 mV p-p	800 mV p-p	800 mV p-p

Table 3.22 Performance

	SD	MD	3G
Jitter	< 370 ps (.09 UI)	< 0.2 UI	< 0.2 UI
Data Rates	143 Mb/s to 540 Mb/s	143 Mb/s to 1.485 Gb/s	143 Mb/s to 3 Gb/s
Overshoot	< 10%	< 10 %	< 10 %
Rise Time	–	Selectable SD/HD rise time via on-board DIP switches	Auto SD/HD

Table 3.23 General

	SD	MD	3G
Partitioning	Up to 8 partitions with independent level assignment	Up to 8 partitions with independent level assignment	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS	Phoenix or web browser via NK-IPS	Phoenix or web browser via NK-IPS
Dimensions	3 RU x 120 mm deep	3 RU x 120 mm deep	3 RU x 120 mm deep
Power Supply	+15 V DC	+15 V DC	+15 V DC

Specifications are subject to change without prior notice.

AES/EBU Digital Audio Level

The AES/EBU level conforms to AES/EBU standards in digital audio streaming.

The NK-D64 is available in 75 Ω BNC models or optional 110 Ω DB-25 models.




Figure 3.19 NK-D64/75 – 75 Ω , 64x64 Rear IO




Figure 3.20 NK-D64/110 – 110 Ω , 64x64 Rear IO

Specifications

Table 3.24 Inputs

Connection	75 Ω BNC (D64/75) 110 Ω DB-25 connectors (D64/110)
Level	1 V p-p (75 Ω) 2-7 V p-p (110 Ω)
Cable EQ	Up to 300 m RG59/U

Table 3.25 Outputs

Connection	75 Ω BNC (D64/75) 110 Ω DB-25 connectors (D64/110)
Clocking	Non-reclocking
Level	1 V p-p (75 Ω) 3-4 V p-p (110 Ω)

Table 3.26 Performance

Jitter	< 2 ns (0.13 UI)
Data Rates	32 kHz to 192 kHz

Table 3.27 General

Partitioning	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS
Dimensions	3 RU x 120 mm deep
Power Supply	+15 V DC

Specifications are subject to change without prior notice.

Stereo Analog Audio Level

All Analog Audio level routers have selectable +4 / -10 dBu input and output levels, via on-board solder links, please refer to “**Appendix B: Analog Audio Router I/O Levels**” on page 7–1.




Figure 3.21 NK-A64 – 64x64 Rear IO

Specifications

Table 3.28 Inputs

Connection	DB-25 Female on chassis (8 audio channels)
Connection Type	Balanced active differential
Input Z	24 K Ω
Nominal Input Level	+4 dBu or -10 dBu (selectable via solder links)
Maximum Input Level	+25 dBu
CMRR	60 dB

Table 3.29 Outputs

Connection	DB-25 Female on chassis (8 audio channels)
Connection Type	Balanced active differential
Output Z	50 Ω
Nominal Input Level	+4 dBu or -10 dBu (selectable via solder links)
Maximum Input Level	+24 dBu

Table 3.30 Performance

THD (Typical)	0.0025 % @ 1 kHz, +4 dB
THD + Noise (Typical)	0.0094 % @ 1 kHz, +4 dB
Level Deviation	± 0.02 dB
Channel Separation	-80 dB maximum

Table 3.31 General


Partitioning	Up to 8 partitions with independent level assignment
Configuration	Phoenix or web browser via NK-IPS
Dimensions	3 RU x 120 mm deep
Power Supply	±15 V DC

Specifications are subject to change without prior notice.

Control Panels

RCP-NK1

The RCP-NK1 40 button panel controls NK Series Routers, it switches and protects outputs, it can also display router status. It has 40 soft, programmable backlit keys, arranged in a 32 + 8 configuration for convenient function key layout.

**Figure 3.22 Front and Rear of RCP-NK1**

Connected via the T-Bus Control System, with CAT5 cables, the RCP-NK1 is phantom powered by the router it is connected to. Multiple control panels can be linked together and powered from the one router.

Panel layout has been designed with 2 rows of 16 keys on the left-hand side, and 2 rows of 4 keys on the right-hand side for users who wish to keep function keys separate from their source, destination and breakaway keys. The LED brightness can be set through the NK-IPS for both on and off states.

Specifications

Table 3.32 Keys

Number	40 backlit keys
--------	-----------------

Table 3.33 General

Configuration	Phoenix or web browser via NK-IPS
Dimensions	1 RU x 25 mm deep
Power Consumption	1.5 watts
Power Supply	+15 V DC phantom power

Specifications are subject to change without prior notice.

RCP-NKM

The RCP-NKM 40 button panel controls NK Series Routers, has a variety of assignable functions, and it can also be used for virtual routing. It has 40 programmable backlit keys, a 16 character by 2 line backlit LCD screen, and can control up to 32 router levels.




Figure 3.23 Front and Rear of RCP-NKM

See the *RCP-NKM Remote Control Panel User Guide* for more information.

RCP-NKQ

The RCP-NKQ control panel has a variety of assignable functions and it can also be used for virtual routing. It has 17 programmable backlit keys, panel linking with other remote control panels, and can control up to 32 router levels.




Figure 3.24 Front and Rear of RCP-NKQ

See the *RCP-NKQ Remote Control Panel User Guide* for more information.

NK-VCP




Figure 3.25 NK-VCP

The NK Virtual Control Panel (NK-VCP), accessible only through the NK-IPS, enables users to remotely control an entire NK system. If required, it is also possible to control multiple systems, alternating between each as needed. The VCP can be purchased as an addition to an existing NK system or can be purchased as part of a new system.

The NK-VCP is built with Java technology, enabling flexibility and cross-platform control. Users are advised to have installed the latest version of the Java Runtime Environment (JRE) before using the VCP. For further information on the VCP and the Java Runtime Environment, please refer to the ***NK-IPS Internet Protocol Server User Guide***.

As the VCP works in conjunction with the NK-IPS, VCP control can be password protected to allow only authorised users to perform router functions. One VCP license is provided with the purchase of an NK-IPS. If further licenses are required, an upgrade file can be purchased and installed.

Please note that as VCP licenses and usage are inherently linked to and modified by the NK-IPS, all configuration and functionality details are outlined in the ***NK-IPS Internet Protocol Server User Guide***.

NK-VRC




Figure 3.26 NK-VRC Editor in the Phoenix Control Surface

The NK Virtual Routing Core (NK-VRC) provides virtual routing for complex NK Series routing switcher systems. The NK-VRC, accessible using the Phoenix Control Surface via the NK-IPS, enables users to map inputs and outputs from routing switchers through to the NK-VRC for control via any remote control panel. These parameters can be saved in a configuration document and sent to an NK-VRC at any time using Phoenix. Therefore, if an NK-VRC is used in a number of different operating scenarios, the configuration can be changed easily and quickly. See the *NK-VRC Virtual Routing Core User Guide* for all configuration and functionality details for the NK-VRC.

Interface and Connectivity

The NK-IPS




Figure 3.27 Front and Rear of NK-IPS

The NK-IPS (Internet Protocol Server) is the device used for configuration of NK Series devices including routers, control panels and control interface devices. Connection of the NK-IPS to either a single computer or a network allows configuration of the NK routers and panels using Phoenix or a web browser, further enhancing the capability

of any installation of NK Series products by providing access to the entire range of functions. The NK-IPS also enables users to configure T-Bus enabled Ross Video devices.




Figure 3.28 NK-IPS Connection Example

The NK-IPS is also required for use of the NK Hub, for information and usage of this software component, please refer to the *NK-IPS Internet Protocol Server User Guide*.

The NK-IPS does not require Internet access for operation, only Phoenix or an Internet browser is required for operation and configuration. For further information, please refer to the *NK-IPS Internet Protocol Server User Guide*.

The NK Hub




Figure 3.29 NK Hub

The NK Hub, accessible only through the NK-IPS, is a software component used to connect two or more NK-IPS devices, enabling NK Series protocol and switch communication between NK Series components connected to each NK-IPS. Internet Protocol Servers can be locally or remotely connected allowing NK Series components to respond to status requests, switch requests and protect requests.




Figure 3.30 NK Hub Example

A local connection enables two NK-IPS devices within the same network to communicate with NK Series components connected to each. A remote connection, via an Internet connection or Virtual Private Network (VPN), allows two or more Internet Protocol Servers to communicate over longer distances.

The NK Hub is built with Java technology, enabling flexibility and cross-platform control. Users are advised to have installed the latest version of the Java Runtime Environment (JRE) before using the NK Hub. For further information on the NK Hub and the Java Runtime Environment, please refer to the *NK-IPS Internet Protocol Server User Guide*.

Please note that as NK Hub connection and usage requires the NK-IPS, all configuration and functionality details are outlined in the *NK-IPS Internet Protocol Server User Guide*.

The NK-3RD

The NK-3RD Third-Party Interface enables a third-party control system to control an NK Series routing switcher system using the SW-P-08 protocol.

The NK-3RD works with any NK Series router and supports crosspoint switch commands and crosspoint status requests. Up to 1024 inputs and 1024 outputs can be controlled and it supports up to 16 levels.




Figure 3.31 Front and Rear of NK-3RD

See the *NK-3RD Third-Party Control Interface User Guide* for more information.

The NK-SCP

The NK-SCP Serial Control Port allows an NK Series routers to be controlled via the Kondor 2 or an external RS-232 device. It is available in RS-232 (NK-SCP/A) and RS-485 (NK-SCP/K2) models. Configuration of either the NK-SCP/A or the NK-SCP/K2, as well as router configuration and partitioning, requires the NK-IPS.



Figure 3.32 NK-SCP/A RS-232 and NK-SCP/K2 RS-485

The NK-SCP/A – RS-232 Control

The NK-SCP/A model allows an RS-232 device, such as an automation system or computer terminal, to control NK routers using the Ross Video EOS ASCII protocol. Any combination of NK routers can be controlled with a maximum size of 255 inputs and 255 outputs with up to 8 levels. The bidirectional protocol incorporates both crosspoint status monitoring and crosspoint switching. Crosspoint switching can be performed using individual levels or through user-defined breakaway mapping.

The NK-SCP/K2 – RS-485 Control

The NK-SCP/K2 allows Kondor 2 routers to be extended by utilizing NK routers as additional levels. Any combination of NK routers can be added to a Kondor 2 system with a maximum size of 255 inputs and 255 outputs with up to 8 levels. Kondor 2 router inputs, outputs and levels are directly mapped to NK Series router inputs, outputs and levels, requiring no user mapping.

The NK-GPI




Figure 3.33 NK-GPI

The NK-GPI is a universal GPI interface for the NK family of routers. Providing both GPI inputs and outputs, the NK-GPI allows flexible GPI control, configured from the NK-IPS Device Properties pages. The NK-GPI also supports both GPI input return and latch modes.




Figure 3.34 NK-GPI Connection Example

NK-GPI configuration, via the NK-IPS and a PC connected to a network, allows users to customize GPI inputs and outputs, as well as the input mode (Latch or Return), and a Panel Link Address, configuring the NK-GPI to be controlled from a connected NK Control Panel.

The T-Bus Control System

NK routers and panels are linked via the T-Bus Control System, a multi-drop RJ-45 control system supporting collision detection and half-duplex communication. The T-Bus Control System minimizes cable connections between devices, acting as both a reliable means to phantom power selected devices and as the communications line.

The T-Bus Control System's collision detection support ensures that if two devices transmit messages at the same time they will not send incorrect data to other devices on the line. All components that utilise the T-Bus Control System are able to monitor communication on the line to ensure that no two devices are transmitting at the same time.

The Heartbeat



Figure 3.35 Heartbeat Display

NK Series routers indicate their status by a pulsating LED, called a heartbeat. The heartbeat flickers when a switch message is handled by the router. It dims slightly to indicate a handled message that did not result in a switch.

The heartbeat is also connected to the alarm status. It monitors the status of the power supply and signifies a problem by pulsating at a noticeably faster rate.

NK Series Router Power Supplies

Each NK router, control panel and control device comes standard with a single external AC/DC power supply. The exceptions to this are devices that are powered from the T-Bus, such as the RCP-NK1, NK-SCP/A and NK-GPI.

Redundant external power supplies are available. Please contact Ross Video.

Optionally, a 100W rack mount redundant power supply, NK-RP1/P, is available to power up to 4 devices. Refer to the *NK-RP1/P User Guide* for additional information.



Figure 3.36 NK-RP1/P and NK-RP1/PN Rear Connectors




Figure 3.37 Example of NK-RP1/P Power Connections

Connecting NK Components

Unpacking and Pre-Installation

After unpacking NK components, please inspect all NK Series components for any signs of damage that may have occurred during transportation. In the event of such damage, please notify a Ross Video representative immediately.

NK Series components should be installed in an adequately ventilated rack frame, ideally in an appropriate environment for audio visual equipment. Relative humidity should be no more than 70% (non-condensing) and temperatures should not exceed 30°C or 86°F.

If the above conditions are not attainable for operation, it is advised that NK Series routers be installed with 1 RU space between them before use.

Connection Overview

NK Series components are connected via the T-Bus multi-drop control system by a single CAT5 Ethernet cable. Routers are supplied with their own power supply, the NK1 panels are phantom powered by the routers they are connected to via the CAT5 cable. Each control panel has two RJ-45 ports for phantom power and communications. When connecting devices, either port may be used to connect panels or routers to each other.




Figure 3.38 Single Panel Connection Example

Panels can be linked together to expand the number of available buttons. Panels are linked if they have the same address and a different device link address that is not 0 (zero). Linked panels behave exactly as if they were one larger panel except that macros can not be appended or added across panels.

The NK-IPS is required to configure linked panels and also for changing individual component addresses.




Figure 3.39 *Linked Panel Connection Example*

Power may also be distributed evenly throughout an NK system by way of direct connections between phantom powered connections (control panels, NK-SCP and NK-GPI) from a common power source (NK Series routers or the NK-IPS), or by daisy chaining components. Daisy chaining components allows several phantom powered components to be connected to the one router.




Figure 3.40 *Daisy-Chain Connection Example*

A maximum of four RCP-NK1 control panels may be connected (daisy-chain) to an individual router at any one time; and a maximum of seven RCP-NK1 control panels to one NK-IPS. Adding other power sources to the same system will contribute further power to the T-Bus connection if required.




Figure 3.41 *T-Bus Distributed Power Example*

Connecting the NK-SCP

Connecting the NK-SCP/A

The NK-SCP/A is connected to a computer or RS-232 device with a straight through RS-232 cable.

The NK-SCP is phantom powered by the T-Bus, allowing the heartbeat to show communication activity when messages and switches are operated from the RS-232 device.




Figure 3.42 SCP/A Connection Example

Connecting the NK-SCP/K2

The NK-SCP/K2 is connected to the Geneos CPU with the parallel to serial converter cable supplied (Part number 9801 2001). If the NK-SCP/K2 and NK routers have been purchased as an addition to a preexisting Kondor 2 and Geneos CPU system, this cable would have been supplied with the initial Kondor 2 / Geneos shipment.

The NK-SCP is phantom powered by the T-Bus, allowing the heartbeat to show communication activity when messages are sent from the Geneos CPU.




Figure 3.43 SCP/K2 Connection Example

Parallel to Serial Converter

The Parallel to Serial converter is housed inside the DB-37 connector shell which plugs into the Parallel Output Control connector located at the bottom left side at the rear of the Geneos CPU frame. Power to the converter is supplied via the DB-25 connector (wired to the DB-37). The DB-25 connector plugs into the AUX connector located at the bottom left side at the rear of CPU frame. The Serial output from the converter is available from the DB-9 plug (wired to the DB-37), this DB-9 plugs into the top RS-485 DB-9 on the Rear left of the Kondor 2 frame. The PC communications cable is wired to the DB-25, the PC end has both a DB-25 and a DB-9 for connection to an RS-232 communications connector on a PC running Geneos.




Figure 3.44 Parallel to Serial Converter

To connect the NK-SCP/K2 to the Geneos CPU:

1. Connect the DB-37 connector of the Parallel to Serial Converter to the Router Control Port on the rear of the Geneos CPU.
2. Connect to DB-25 connector of the Parallel to Serial Converter to the Auxiliary Port on the rear of the Geneos CPU.
3. Connect the single DB-9 connector of the Parallel to Serial Converter to the DB-9 connector of the NK-SCP/K2. Alternatively, this connector can be connected to the Kondor 2 frame itself, and the NK-SCP/K2 connected to the frame via a serial cable.
4. Connect either the linked DB-25 or the DB-9 to a PC for Geneos software configuration and control.



The NK-SCP/K2 can be connected to the Geneos CPU at any time, but to ensure status updates are completed, it is recommended that it be connected after configuration details have been entered on both the Device Properties page via the NK-IPS, and the Geneos Software.

Connecting the NK-SCP to the T-Bus Control System

To connect the NK-SCP/K2 or NK-SCP/A to the T-Bus Control System follow the steps below:

1. Connect one end of a straight through CAT5 cable to the RJ-45 connector on the SCP.
2. Connect the other end of the CAT5 cable to any available T-Bus port on the NK-IPS, or any other T-Bus compatible device connected to the NK-IPS.

Connecting the NK-GPI

The NK-GPI connects to the T-Bus control system using the RJ-45 connectors on the box edge. The loop through connector allows the NK-GPI to reside at any point on the control bus. The NK-GPI connects to general purpose interface inputs and outputs via a DB-37 port.

NK-GPI Pinouts




Figure 3.45 NK-GPI Pinouts

Connecting GPI Inputs

Use **Figure 3.46** to wire NK-GPI inputs; refer to **Figure 3.45** for input pin numbers.




Figure 3.46 GPI Input Connection

Connecting GPI Outputs

Use **Figure 3.47** to wire NK-GPI output; refer to **Figure 3.45** for output pin numbers.

The example diagram uses a LED to indicate status. The LED can be replaced with another indicator, load or a GPI input from another device.




Figure 3.47 GPI Output Connection



When connecting GPI outputs to the NK-GPI, users must remember there is a 10 mA current limit on each output, and a resistor must be connected to the GPI output to maintain peak operation. **Figure 3.47** depicts how to wire outputs correctly.

Customizing RCP-NK1 Control Panels

Overview

One of the flexible features of the NK Series of routers and panels is the ability to install RCP-NK1 control panels either locally or remotely to NK-16 routers. Localizing panels ensures that rack space is maximized and cable connections are minimized. Remotely installing panels means that panels do not necessarily have to be installed in the immediate vicinity of the routers, and can be connected and installed in other rooms if required.


Localizing the Panel

If users are localizing control panels, a short (between 12.5 and 20cm or 5 and 8") standard (not crossover) CAT5 cable is required to connect the panel to the router internally.


Ensure that the router and the panel you wish to localise are not connected to any other devices before proceeding. Also ensure that both the router and the control panel are disconnected from the power source.

To fit the control panel locally to the front of the router:

1. Remove the front button panel from the case it was originally shipped in.



2. Remove the front panel of the router.




3. Disconnect the wire that connects the heartbeat to the circuit board.



4. Connect one end of the CAT5 cable to either of the control panel's RJ-45 ports.



5. Connect the other end of the CAT5 cable to the internal RJ-45 of the router.



6. Ensure the excess cable is packed in the empty space of the casing before attaching the panel face.



7. Slowly clip the button panel into the router casing, on both the left and the right sides.



8. When the face is firmly in place on the router casing, it can be installed as any normal router, saving rack space.



Customizing RCP-NK1 Button Labels

The button labels of the RCP-NK1 may be customized to suit the needs of any application. Button labels may be customized in any word processing, spreadsheet or design software providing that the label size is set to exactly 9.5 x 9.5 mm (3/8" x 3/8").

It is recommended that labels be printed on overhead transparency rather than paper so that LED illumination is not obscured.

Configuration

Default Configuration

Overview

When NK Series components are shipped, the default configuration is set to allow both NK routers and control panels to be used straight out of the box.

No matter how large or small the system, each is individually configured and tested by Ross Video engineers.

RCP-NK1 Control Panel Default Configuration

Key Assignment Default

The RCP-NK1 control panel is factory configured with the key assignments as depicted in **Figure 4.1**.




Figure 4.1 RCP-NK1 Control Panel Default Configuration

Further configuration and key panel settings, as well as router configuration, can be accessed using the NK-IPS and Phoenix or a web browser.

When purchasing a complete NK system, the RCP-NK1 will be custom programed so that it can be used straight out of the box without further configuration via the NK-IPS. Further documentation depicting key panel layout will be provided with systems that do not adhere to the factory default.

The key functions listed below are assigned to buttons in the factory default configuration of the RCP-NK1.

DESTINATION

Changes the destination the panel is controlling.

The bottom, left hand row of 16 keys selects destinations 1-16 on the default page/set. When the DESTINATION SHIFT key has been pressed, the second page of destinations (17-32) is accessible.

SOURCE

Switches using the current destination and level pattern.

The top left hand row of 16 keys selects the sources 1-16 on the default page/set.

When the SOURCE SHIFT key has been pressed, the second page of sources (17-32) is accessible.

DESTINATION SHIFT	Changes the destination page of the panel
SOURCE SHIFT	Changes the source page of the panel.
LEVEL	Toggles the specified level number from the current level pattern. Four Level keys are available on the factory default configuration: Level 2 - SDI Video Level 5 - Analog Video Level 6 - Analog Audio (Left channel) Level 7 - Analog Audio (Right channel)
MACRO	Records key press events that can be replayed later.
BREAKAWAY	Selects a preconfigured breakaway level pattern.

Keys that are not available on the factory default configuration of the RCP-NK1, but may be assigned and configured via the NK-IPS, are listed below.

CROSSPOINT	Switches the input, output and level/breakaway associated with this key.
BREAKAWAY STEP	Steps through breakaways.
PROTECT	Protects the currently selected output/level pair. The PROTECT key also activates the panel lock function.
TAKE	Confirms input key events. After a switch is set up, press the TAKE key to activates the switch.
CHOP	Alternates between the last two selected inputs.
DEASSIGN	Allows users to reset a destination assignment.
MACHINE CONTROL KEY	Toggles on/off RS-422 Machine Control reciprocal switching.
PANEL LOCK	Activates the panel lock function, for environments where a PROTECT KEY is not required.
UNASSIGNED	Key is not assigned any function or value.

NK Series Router Levels Default

The factory default configuration breakaway and levels for the NK routers is as depicted in **Table 4.1**.

Table 4.1 Configuration Breakaway and Levels for the NK Routers

	3G/HD/SD Video	SD Video	AES/EBU Audio (1)	AES/EBU Audio (2)	Analog Video	Analog Audio (Left)	Analog Audio (Right)	Machine Control
Default	✓	✓	✓	✓	✓	✓	✓	✓
Level 1	✓							
Level 2		✓						
Level 3			✓					
Level 4				✓				
Level 5					✓			
Level 6						✓		
Level 7							✓	
Level 8								✓

RCP-NKM/Q Control Panel Default Configuration

The RCP-NKM and RCP-NKQ default configuration is viewed by opening the editor for the device in the Phoenix Control Surface.

See the *RCP-NKM Remote Control Panel User Guide* for more information about the RCP-NKM default configuration.

See the *RCP-NKQ Remote Control Panel User Guide* for more information about the RCP-NKQ default configuration.

Key Assignments Default

By default, the 20 keys in the top row on the RCP-NKM are assigned as sources and the 20 keys in the bottom row are assigned as destinations.



Figure 4.2 RCP-NKM Control Panel Default Configuration

By default, the RCP-NKQ has these key assignments:

- keys 1 to 6: destinations (outputs 1 to 6 respectively)
- keys 7 to 13: sources (inputs 1 to 7 respectively)
- key 14: Level 1 (MD)
- key 15: Macro 1
- key 16: Menu 1
- key 17: Menu 2



Figure 4.3 RCP-NKQ Control Panel Default Configuration

Breakaways Default

The default breakaway is tied, that is, the first eight router levels are switched together when requested from the RCP-NKM or RCP-NKQ.

Router Levels Default

The RCP-NKM and RCP-NKQ send switch requests to the routing switcher. Each routing switcher is assigned a level, or number of levels if it has been partitioned.

Table 4.2 RCP-NKM/Q Default Router Levels

Router Level	Name
1	Multi-definition video
2	Serial digital interface video
3	AES/EBU digital audio 1
4	AES/EBU digital audio 2
5	Analog video
6	Analog audio (left)
7	Analog audio (right)
8	Machine control

Configuring Routers

Overview

If a simple, standard setup is all that is required, NK Series routers can be used straight out of the box. After unpacking the NK Series router and connecting the inputs and outputs, the system is ready to go. Where an alternative configuration is required, the NK-IPS allows unparalleled configuration using the web interface on the NK-IPS or with Phoenix.

The NK Series routers have an input and output range of 1 to 65535 that can be set on up to 32 levels. Routers may be configured identically using the web interface on the NK-IPS or with Phoenix, in which case they will switch at the same time. Routers maintain status for their output range and also retain that status between power down cycles. Routers also maintain protect information for their output range. A control panel can protect a specified output, if another device attempts to switch that output, it will be denied.

Routers may be configured to have internal partitions. These are always a factor of the maximum size; for example, a 32x32 router can be two 16x16 routers, three 10x10 routers, four 8x8 routers, five 6x6 routers, seven 4x4 routers or eight 4x4 routers. Where there are unused crosspoints due to partitioning, they will be the last inputs and outputs.

Configuration Options — NK-IPS

The router Device Properties page, accessible through the NK-IPS, allows users to configure interface and usability options for all NK Series routers and also displays the alarm status of the router, as well as having the unique ability to assign names and brief descriptions for the devices themselves.

For details on how to query devices and use of the NK-IPS, refer to the *NK-IPS Internet Protocol Server User Guide*.

[illegible]

Figure 4.4 Router Device Properties Page

Device Properties Fields

Family

The Family name is set in the factory before shipping and displays the family that the device belongs to. This parameter is read-only.

Family NKseries

Device

The Device name is set in the factory before shipping and displays the name assigned to the device. This parameter is read-only.

Device NK-A64

Serial Number

The Serial Number is set in the factory before shipping and is unique to each device. This parameter is read-only.

Serial Num 0000015991

Name

The Name field can be assigned by the user to uniquely name a device. This field has a maximum of 16 characters and is used for description and identification only.

Name Ross Video

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use. This field has a maximum of 16 characters and is used for description and identification only.

Details

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas. This field has a maximum of 10 characters and is used for description and identification only.

Group

Configuration Fields

Address

The Address is used within the overall control system to identify devices. Each device must be given a unique Address to avoid hardware and communication conflicts. The valid value range for assigning an individual device Address is 2-255.

Address 254

Ignore Out Of Range Inputs

The Ignore Out of Range Inputs option will ignore switches on an offset router that has been configured to the same level as another connected router. By default, the Ignore Out of Range Inputs option is not active (the check box is cleared).

Ignore Out Of Range Inputs ☐

★ The Ignore Out of Range Inputs option is only available on the NK-64 and NK-72 routers and is only used for specific installations.

Switching Point

Switching Point: ☒ SD (PAL/NTSC) ☐ HD (1125_50/60_I) ☐ Custom

Custom Switching Line (NK-64 Routers only)

Custom Switching Line (1 to 625)

Custom Switching Position (NK-64 Routers only)

Custom Switching Position (0 to 63)

Number of Partitions

The Num Partitions (Number of Partitions) indicates how you wish the router to be partitioned. The default value of the partitions is 1 (no partitions.), the maximum value is 8.

Num Partitions (1 to 8)

Table 4.3 shows the relative input and output sizes to the number of partitions configured for 16x16, 32x32, 64x64 and 72x72 routers.

Table 4.3 Relative input and output sizes to the number of configured partitions

16x16 Router		32x32 Router		64x64 Router		72x72 Router	
Partitions	I/O Size	Partitions	I/O Size	Partitions	I/O Size	Partitions	I/O Size
1	16x16	1	32x32	1	64x64	1	72x72
2	8x8	2	16x16	2	32x32	2	36x36
3*	5x5	3*	10x10	3*	21x21	3	24x24
4	4x4	4	8x8	4	16x16	4	18x18
5*	3x3	5*	6x6	5*	12x12	5*	14x14
6*	2x2	6*	5x5	6*	10x10	6	12x12
7*	2x2	7*	4x4	7*	9x9	7*	10x10
8*	2x2	8	4x4	8	8x8	8	9x9

* Denotes that partition leaves unusable inputs/outputs as ‘remainders’.

When partitioning routers, some configurations will leave ‘remaindered’ inputs and outputs. Any division of the router that leaves a remainder will not use the remaining inputs and outputs. For example, a 32x32 partitioned into 3, will be equivalent to three 10x10 routers (30 inputs and 30 outputs in total). The last two inputs and the last two outputs will remain unused and inaccessible for router functions.

Partition Levels

The Partition Levels table allows users to configure levels to each partition. Selecting a level, by selecting a check box in the Levels column, assigns that level to a partition number from the Part. Num. column.

Levels can be assigned more than once to different or distinct partitions, but only one level can be selected for each partition.

[illegible]

Figure 4.5 *Partition Levels*

Control Layer Partitions (NK-A64 only)

The NK-A64 Analog Audio Level Router has a control layer in addition to the first and second levels (left and right channels respectively). The control layer is used for lossless signal mixing, for more information, refer to “**NK-A64 Control Layer**” on page 5-12.

The Control Layer Partition table allows users to configure levels to each partition. Selecting a level, by selecting a check-box in the Levels column, assigns that level to a partition number from the Part. Num. (Partition Number) column.

Levels can be assigned more than once to different or distinct partitions, but only one level can be selected for each partition.

Partition Levels	
Part. Num.	Levels
1	
2	
3	
4	
5	
6	
7	
8	

Figure 4.6 *Control Layer Partitions*

First Input

The First Input defines the first source used (from the range of 1-255) by the router. The valid range for the First Input is 1-65535, the default is 1.

First Input 1

First Output

The First Output defines the first destination used (from the range of 1-255) by this router. The valid range for the First Output is 1-65535, the default is 1.

First Output 1

Machine Control Destination (NK-M Routers only)

The Machine Control Destination radio buttons specify whether the destinations are used as the Slave or as the Master.

Machine Control Destination is: ☐ Slave ☒ Master

★ The Machine Control Destination option is only available on the Machine Control router's Device Properties page. It is not applicable to other NK router models.

Status Fields

Reference Signal Type

The Reference Signal Type automatically detects if a video reference is being looped through the router. It will show the signal type if there is a reference present, either PAL or NTSC, or, if no reference is detected, it will display Local.

Reference Signal Type Local

The Local signal is the internal random switching pulse that is generated by the router to ensure successful switch timing. For more information on video referencing, please refer to “**Video Referencing**” on page 5–17.

Alarms

The Alarms status section of the Device Properties page is divided into three headings: Reference, Matrix Power and RCP Power. The NK-64 routers also have an additional alarm warning for I/O Power.

There are four degrees of alarm urgency: Green (Normal operation), Yellow (Warning), Orange (Error) and Red (Critical Error). The possible Reference, Matrix Power, and RCP Power statuses are displayed in **Table 4.4**.


Table 4.4 Alarms

Heading	Possible Status	Alarm Urgency	Status Color
Reference	No Reference Detected	Warning	Yellow
	Reference Present	None (Safe)	Green
Matrix Power	Matrix Power Error	Critical Error	Red
	Matrix Power OK	None (Safe)	Green
RCP Power	RCP Power Error	Critical Error	Red
	RCP Power OK	None (Safe)	Green
I/O Power (NK-64 only)	I/O Power OK	None (Safe)	Green
	I/O Power Error	Critical Error	Red

Reference

The Reference status alarm indicates if there if a video reference connected to the router. It will also display the format of the reference, either PAL or NTSC. If a video reference is connected, the router will attempt to perform all switches during the vertical interval of the reference. If there is no reference connected, the router will still function,

but the switches may be activated by the router at any time. For more information on the NK video/switching reference feature, please refer to “**Video Referencing**” on page 5–17.

 **Reference** No Reference Detected

Matrix Power

The Matrix Power status alarm indicates the power status of the router. A router that displays any alarm status other than Green (safe) should be switched off and unplugged. Another power pack can be used to test the router frame again, but if the status alarm remains on the Device Properties page, a Ross Video representative should be contacted.

 **Matrix Power** Matrix Power OK


RCP Power

The RCP Power status alarm indicates the power status that the router distributes to the control panels connected to it. For any alarm status other than Green (safe), panels should be disconnected one by one, and the alarm status checked. In some instances there may be too many devices connected to the router to ensure regulated power consumption by each device. If all devices have been disconnected from the router and the alarm status remains activated, the router should be switched off and unplugged. Another power pack can be used to test the router frame again, but if the alarm status remains higher than Green on the Device Properties page, a Ross Video representative should be contacted.

 **RCP Power** RCP Power OK

I/O Power (NK-64 Routers only)


The I/O Power status alarm indicates the I/O card status for the router. As NK-64 routers are comprised of 8 separate I/O cards, each card has its own alarm. If any card has a fault or fails during operation, the I/O Power status alarm will be triggered. If the alarm has been triggered, each input and output card should be checked individually before using the router for further operations.

 **I/O Power** I/O Power OK

Submit and Upgrade Fields

Submit Settings




The Submit Settings button will upload the settings to the device.



If users wish to cancel or ignore the settings they have made, click the Online tab to return to the Online Devices page, or click the Refresh button of your browser to revert to the original settings displayed.

Upgrade Firmware

The Upgrade Firmware button is used to upload to the device the latest firmware, contained in a binary file. Upgrading firmware allows new features, enhancements and improvements of the NK router to be installed.

Configuration Options — Phoenix

Any device that can be configured from a web browser via the IPS may also be configured by the Phoenix Control Surface with the default interface.




Figure 4.7 Phoenix Router Configuration Window

Device configuration is implemented by the use of text fields, check-boxes, radio buttons and other user-entered or user-modifiable fields. Configuration fields may differ, depending on the functionality of the device. For full configuration field details, please consult the user guide of the device.

Device Details Fields

Name

The Name field can be assigned by the user to uniquely name a device.

Name:

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas.

Group:

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use.

Details:

Address

The Address is used within the overall control system to identify devices. Each device must be given a unique Address to avoid hardware and communication conflicts.

Address:

Configuration Fields

First Input

The First Input defines the first source used (from the range of 1-255) by the router. The valid range for the First Input is 1-65535, the default is 1.

First Input:

First Output

The First Output defines the first destination used (from the range of 1-255) by this router. The valid range for the First Output is 1-65535, the default is 1.

First Output:

Number of Partitions

The Num Partitions (Number of Partitions) indicates how you wish the router to be partitioned. The default value of the partitions is 1 (no partitions.), The maximum value is 8.

Num Partitions:

Partition Levels

Part. Num.	Levels																															
1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
3	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
4	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
5	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
6	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
7	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																
8	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32																

The Partition Levels table allows users to configure levels to each partition. Selecting a level, by clicking on a radio button in the Level Mask column, assigns that level to a partition number from the Part. Num. column.

Levels can be assigned more than once to different or distinct partitions, but only one level can be selected for each partition.

Machine Control Destination (NK-M Routers only)

The Machine Control Destination radio buttons specify whether the destinations are used as the Slave or as the Master.

- ★ The Machine Control Destination option is only available on the Machine Control router's Device Properties page. It is not applicable to other NK router models.

Other Fields

Ignore Out Of Range Inputs

The Ignore Out of Range Inputs option will ignore switches on an offset router that has been configured to the same level as another connected router. By default, the Ignore Out of Range Inputs option is not active (the check box is not checked).

Ignore Out Of Range Inputs: ☐

- ★ The Ignore Out of Range Inputs option is only available on the NK-64 and NK-72 routers and is only used for specific installations.

Reference Fields

Switching Point

Switching Point: ☐ SD (PAL/NTSC) ☒ HD (1125_50/60_I) ☐ Custom

Custom Switching Line (NK-64 Routers only)

Custom Switching Line:

Custom Switching Position (NK-64 Routers only)

Custom Switching Position:

Status Fields

Reference Signal Type

The Reference Signal Type automatically detects if a video reference is being looped through the router. It will show the signal type if there is a reference present, either PAL or NTSC, or, if no reference is detected, it will display Local.

Reference Signal Type: Local

Alarms Fields

The Alarms section divided into three headings: Reference, Matrix Power and RCP Power. The NK-64 routers also have an additional alarm warning for I/O Power.


There are four degrees of alarm urgency: Green (Normal operation), Yellow (Warning), Orange (Error) and Red (Critical Error). The possible Reference, Matrix Power and RCP Power statuses are displayed in **Table 4.5**.

Table 4.5 Alarms

Heading	Possible Status	Alarm Urgency	Status Color
Reference	No Reference Detected	Warning	Yellow
	Reference Present	None (Safe)	Green
Matrix Power	Matrix Power Error	Critical Error	Red
	Matrix Power OK	None (Safe)	Green
RCP Power	RCP Power Error	Critical Error	Red
	RCP Power OK	None (Safe)	Green
I/O Power (NK-64 only)	I/O Power OK	None (Safe)	Green
	I/O Power Error	Critical Error	Red

Reference

The Reference status alarm indicates if there if a video reference connected to the router. It will also display the format of the reference, either PAL or NTSC. If a video reference is connected, the router will attempt to perform all switches during the vertical interval of the reference. If there is no reference connected, the router will still function, but the switches may be activated by the router at any time. For more information on the NK video/switching reference feature, please refer to “**Video Referencing**” on page 5–17.

Reference:  No Reference Detected

Matrix Power

The Matrix Power status alarm indicates the power status of the router. A router that displays any alarm status other than Green (safe) should be switched off and unplugged. Another power pack can be used to test the router frame again, but if the status alarm remains on the Device Properties page, contact Ross Technical Support.

Matrix Power:  Matrix Power OK

RCP Power


The RCP Power status alarm indicates the power status that the router distributes to the control panels connected to it. For any alarm status other than Green (safe), panels should be disconnected one by one, and the alarm status checked. In some instances there may be too many devices connected to the router to ensure regulated power consumption by each device. If all devices have been disconnected from the router and the alarm status remains activated, the router should be switched off and unplugged. Another power pack can be used to test the router frame again, but if the alarm status remains higher than Green on the Device Properties page, contact Ross Technical Support.

RCP Power:  RCP Power OK

I/O Power (NK-64 Routers only)

The I/O Power status alarm indicates the I/O card status for the router. As NK-64 routers are comprised of 8 separate I/O cards, each card has its own alarm. If any card has a fault or fails during operation, the I/O Power status alarm will be triggered. If the alarm has been triggered, each input and output card should be checked individually before using the router for further operations.

Device Properties Fields



NK - 3G72 - Properties	
Device Information	
details	
familyName	NKseries
deviceTypeName	NK-3G72
version	2.0
serialNum	0000027555
groupID	
localAddress	55
flags	2

Figure 4.8 Device Properties Fields

Configuring the RCP-NK1 Panel

Overview

All NK Series components are preconfigured and can be used with the factory default setup immediately after being installed, without the need for additional configuration. Where an alternative configuration is required, the NK-IPS allows unparalleled configuration using little more than a PC and Phoenix or a web browser.

The RCP-NK1 40 button panel controls NK Series routers, displaying router status, switching and protecting crosspoints. It has 40 soft, programmable backlit keys, with 8 being physically separate for convenient function key layout. The LED brightness can be set through the NK-IPS for both on and off brightness.

Each panel is capable of controlling the whole address space for the NK system (1-65535 inputs and outputs on 32 levels). Panels operate in XY mode by default, but can easily be configured to work in dual cutbus mode using the NK-IPS.

Control Panels can be linked together if they have the same address and a different panel link address (that is not 0). Linked panels behave exactly as if they were one larger panel with the exception that macros can not be appended or added across panels. The panels communicate using the T-Bus protocol with support for collision detection.

Each key can be assigned a function, with up to 3 parameters (Default, Shift1 and Shift2). This function will be called when that switch is pressed. The key functions are:

DESTINATION	Changes the destination that the panel is controlling. If the DESTINATION KEY is not active, the default value is selected. When the DESTINATION KEY has been selected first, the relative destination is selected.
SOURCE	Switches the input using the current destination and level pattern. If the SOURCE KEY is not active, the default value is switched. When the SOURCE KEY has been selected first, the relative source is switched.
CROSSPOINT	Switches the input, output and level/breakaway associated with this key.
LEVEL	Toggles this level number from the current level pattern.
BREAKAWAY	Selects a preconfigured breakaway level pattern.
BREAKAWAY STEP	Steps through breakaways.
MACRO	Records key events that can be replayed later.
PROTECT	The PROTECT key attempts to protect the currently selected output/level pair.
TAKE	The TAKE key confirms input key events. The user sets up a switch, and presses the TAKE key to activate the switch.
CHOP	Alternates between the last two selected inputs.
SHIFT	Changes the source or destination page of the panel.
DEASSIGN	Allows users to reset a destination assignment.
MACHINE CONTROL	Toggles on/off RS-422 Machine Control for reciprocal switching.
PANEL LOCK	Locks the panel from all switches or function key operation.
UNASSIGNED	Key is not assigned any function or value.

RCP-NK1 Configuration

The Device Properties page, accessible through the NK-IPS, allows users to configure interface and key assignments for RCP-NK1 control panels, as well as having the unique ability to assign names and brief descriptions for the devices themselves.

For More Information on...

- how to query devices, and use of the NK-IPS, refer to the *NK-IPS Internet Protocol Server User Guide*.
- how to configure RCP-NK1 via Phoenix, refer to the *Phoenix Online Help Guide*.




Figure 4.9 RCP-NK1 Device Properties Page

Device Properties Fields

Family

The Family name is set in the factory before shipping and displays the family that the device belongs to. This parameter is read-only.

Family NKseries

Device

The Device name is set in the factory before shipping and displays the name assigned to the device. This parameter is read-only.

Device RCP-NK1

Serial Number

The Serial Number is set in the factory before shipping and is unique to each device. This parameter is read-only.

Serial Num 0000015991

Name

The Name field can be assigned by the user to uniquely name a device. This field has a maximum of 16 characters and is used for description and identification only.

Name NK 40 Key Panel

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use. This field has a maximum of 16 characters and is used for description and identification only.

A rectangular input field with a light gray border. The word "Details" is printed in a bold, dark gray font at the top left of the field.

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas. This field has a maximum of 10 characters and is used for description and identification only.

A rectangular input field with a light gray border. The word "Group" is printed in a bold, dark gray font at the top left of the field.

Configuration Fields

Address

The Address is used within the overall control system to identify devices. Each device must be given an unique Address to avoid hardware and communication conflicts. The valid value range for assigning an individual device Address is 2-255.

A rectangular input field with a light gray border. The word "Address" is printed in a bold, dark gray font at the top left of the field, and the number "254" is entered in the field.

When linking multiple control panels, each device must be given the same address to communicate to other devices as one panel, but a different Panel Link Address must be given to prevent internal control system conflicts.

Breakaways

Breakaways								
Breakaway num	level mask (1 ... 8)							
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
9	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
11	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
12	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
13	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
14	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
16	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

The Breakaways table is used to assign levels to breakaways. Users can customize their breakaways to include any levels desired. Levels can be utilized in as many breakaways as is needed.

Checking the boxes representing levels 1-8 next to the breakaways (1-16) will include that level in that breakaway, when the BREAKAWAY or BREAKAWAY STEP keys are pressed.

Different breakaways can be defined for each panel. This is configured in each panel's Device Properties page via the NK-IPS.

Key Definitions

Key Definitions				
Key num	Function	Default	Shift1	Shift2
1	Source ▼	1	17	33
2	Source ▼	2	18	34
3	Source ▼	3	19	35
4	Source ▼	4	20	36
5	Source ▼	5	21	37

The Key Definitions table is where the buttons of the RCP-NK1 are assigned. Any function can be assigned to any key. The keys are represented in the first column by their respective number (1-40). Keys 1-20 represent the first row of keys on the RCP-NK1 and keys 21-40 represent the second row of keys on the panel.

The desired key function is selected from the drop down box in the second column (Function column). Any function can be assigned to any key on the panel and keys can be assigned multiple times.

Details of parameters used in the Key Definition table are explained in detail in **Table 4.6**. For brief descriptions of the keys, please refer to “**Overview**” on page 4–13; for key operation and usage, refer to “**Operation**” on page 5–1.

The Shift1 and Shift2 values only apply to SOURCE, DESTINATION and CROSSPOINT keys, all other keys only require the Default value to be defined, and some keys require no user defined values for operation. All Shift1 and Shift2 values are ignored when not assigned to SOURCE, DESTINATION or CROSSPOINT keys.

Cutbus Destination 1

Configures the Cutbus destination of the top row of keys when no DESTINATION or CROSSPOINT keys have been assigned. The valid range for the Cutbus Destination 1 is 1-255.

Cutbus Dest 1 1

Cutbus Destination 2

Configures the Cutbus destination of the bottom row of keys when no DESTINATION or CROSSPOINT keys have been assigned. The valid range for the Cutbus Destination 2 is 1-255.

Cutbus Dest 2 1

Breakaway Reset

When enabled the Breakaway Reset option resets to the first breakaway (Default Breakaway) after a crosspoint switch. By default, the Breakaway Reset is off (check box is cleared).

Breakaway Reset ☐

Breakaway Warning Mode

The Breakaway Warning Mode determines which breakaway the current switch status is compared with to check if a Breakaway Warning condition has occurred. Two modes are available, Current (Current Breakaway) and Default (First Breakaway).

Breakaway Warning Mode Current ▼

On Brightness

The On Brightness sets the LED brightness for the RCP-NK1 control panel buttons when the button is 'on'; that is when it has been pressed, is already active, or when indicating an error by several quick flashes. The default value is 200. The valid input value range is 1-250.

On Brightness 150 (1 to 250)

The On Brightness does not necessarily have to be a higher value than that of the Off Brightness, although it is generally advised to avoid confusion.

Table 4.6 Configuration Values

Key	Default Value	Shift Value	Shift2 Value	Value Range
Dest	(Output) #	(DESTINATION SHIFT 1) Output #	(DESTINATION SHIFT 2) Output #	Output = 1-65535
The value range for DESTINATION keys is 1-255, representing any valid output value. There may be three pages/sets of DESTINATION keys on any one panel (the default page, first DESTINATION SHIFT page and one second DESTINATION SHIFT page).				
Source	(Input) #	(SOURCE SHIFT 1) Input #	(SOURCE SHIFT 2) Input #	Input = 1-65535
The value range for SOURCE keys is 1-255, representing any valid input value. There may be three pages/sets of SOURCE keys on any one panel (the default page, first SOURCE SHIFT page and one second SOURCE SHIFT page).				
Xpoint	(Destination) #	(Source) #	(Breakaway/Level) #	Source/Destination = 1-255 Breakaway = 1-16 Level = 17-24 (Level # +16)
The CROSSPOINT key requires a destination value, a source value, and a breakaway or level value to be correctly defined.				
Level	(Level) #	—	—	Level = 1-32
For details on levels and formats, please refer to “ Default Configuration ” on page 4–1.				
Breakaway	(Breakaway) #	—	—	Breakaway = 1-16
For details on assigning breakaways, please refer to “ Breakaways ” on page 4–17.				
Brk Step	—	—	—	—

Table 4.6 Configuration Values

Key	Default Value	Shift Value	Shift2 Value	Value Range
The BREAKAWAY STEP key is a function key that, once assigned, does not require any user defined values to operate.				
Macro	(Macro) #	—	—	Macro = 1-40
The valid range for the MACRO key is 1-40. (Up to 40 MACRO keys can be assigned to one panel.)				
Protect	—	—	—	—
The PROTECT key is a function key that, once assigned, does not require any user defined values to operate.				
Take	—	—	—	—
The TAKE key is a function key that, once assigned, does not require any user defined values to operate.				
Chop	—	—	—	—
The CHOP key is a function key that, once assigned, does not require any user defined values to operate.				
Shift	(Shift) #	—	—	Shift = 1-4 1 = DESTINATION SHIFT 1 2 = DESTINATION SHIFT 2 3 = SOURCE SHIFT 1 4 = SOURCE SHIFT 2
Defines the value of the SHIFT key, can be assigned as either a DESTINATION SHIFT or a SOURCE SHIFT.				
Deassign	—	—	—	—
The DEASSIGN key is a function key that, once assigned, does not require any user defined values to operate.				
MC Key	—	—	—	—
The MACHINE CONTROL key is a function key that, once assigned, does not require any user defined values to operate.				
Panel Lock	—	—	—	—
The PANEL LOCK key is a function key that, once assigned, does not require any user defined values to operate.				
Unassigned	—	—	—	—
UNASSIGNED means that the key has no function or value assigned.				

*A dash (—) indicates that user defined values are not required and that any value entered here will be ignored.

Off Brightness

The Off Brightness sets the LED brightness for the RCP-NK1 control panel buttons when the button is ‘off’; that is when it has not been pressed and is not already active. The default value is 50. The valid input value range is 1-250.

Off Brightness (1 to 250)

The Off Brightness does not necessarily have to be a lower value than that of the On Brightness, although it is generally advised to avoid confusion.

Panel Locked

The Panel Locked check box indicates when the panel has been locked to not respond to key presses. By default, this feature is off.

Panel Locked ☐

Panels can be locked by clicking on the Panel Locked check box, by pressing the PANEL LOCK key once or by holding down the PROTECT key (if one has been assigned) for about 3 seconds.

Machine Control Enabled

The Machine Control Enabled option allows reciprocal switching when the check box is checked. By default, Machine Control Enabled is turned off (the check box is not checked).

Machine Control Enabled ☐

★ If the Machine Control Enabled option is checked on the control panel's Device Properties page, all switches activated from the panel will be reciprocal regardless of whether or not there is an MC KEY assigned to the panel.

Machine Control Level

The Machine Control Level configures the level that the machine control (if connected) switches reciprocally when switches are performed. The valid range for this field is 1-32 (representing levels).

Machine Control Level 8 (1 to 8)

★ If an invalid level (above 32) is entered for the Machine Control Level then the level will default to 32 when the settings are updated to the panel, regardless of whether the Machine Control Enabled option has been set or not.

Panel Link Address

The Panel Link Address is required when users wish to use multiple control panels as one linked panel. When linking panels, the Address field must be the same for each panel, whereas the Panel Link Address must be different for each individual panel. By default, the Panel Link Address is set to 0. The valid value range for linking panels is 1-254.

Panel Link Address 0

Clear Protect

The Clear Protect check box will clear any protects on the panel when the **Submit Settings** button has been clicked.

Clear Protect(s) ☐

Comms Retry Delay

The Comms Retry Delay configures the delay (in milliseconds) by which the panel resends data in instances where an error has occurred. Errors may be encountered when the NK system is operating over a large network or when remote panels are being used over long distances. By default, the Comms Retry Delay value is set at 5 (milliseconds) and the valid range is 1 to 65,536 (milliseconds).

Comms Retry Delay 5 (1 to 5000)


Typically, larger systems or systems operated across multiple networks or VPNs will require larger values. Nominally, the following values are recommended for specific standard configurations:

- **Single network system:** 5 ms
- **Single network system (via NK Hub):** 250 to 500 ms
- **VPN or Internet system (via NK Hub):** 500 to 750 ms

Alarms

Protect Alarm

The Protect Alarm indicates whether an output has been protected from the control panel. The Protect Alarm status is also displayed on the NK-IPS Online Devices page and in Phoenix.



Submit and Upgrade Fields

Submit Settings


The Submit Settings button will upload the settings to the device.



If users wish to cancel or ignore the settings they have made, click the Online tab to return to the Online Devices page, or click the Refresh button of your browser to revert to the original settings displayed.

Upgrade Firmware

The Upgrade Firmware button is used to upload to the device the latest firmware, contained in a binary file. Upgrading firmware allows new features, enhancements and improvements of the RCP-NK1 to be installed.



Configuring the NK-SCP

NK-SCP/A Configuration

The NK-SCP/A requires breakaway and baud rate configuration only via the NK-IPS for use. When connected to the T-Bus Control System it will be displayed on the NK-IPS Online Devices pages. The NK routers to be interfaced by the NK-SCP/A can be configured individually on the Device Properties page, accessed via the NK-IPS, of each router.

For details on how to configure NK-SCP/A via Phoenix, refer to the *Phoenix Online Help Guide*.




Figure 4.10 NK-SCP/A Device Properties Page

Device Properties Fields

Family

The Family name is set in the factory before shipping and displays the family that the device belongs to. This parameter is read-only.

Family NKseries

Device

The Device name is set in the factory before shipping and displays the name assigned to the device. This parameter is read-only.

Device SCP/A

Serial Number

The Serial Number is set in the factory before shipping and is unique to each device. This parameter is read-only.

Serial Num 0000015991

Name

The Name field can be assigned by the user to uniquely name a device. This field has a maximum of 16 characters and is used for description and identification only.

Name NK - SCP / A

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use. This field has a maximum of 16 characters and is used for description and identification only.

Details

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas. This field has a maximum of 10 characters and is used for description and identification only.

Group

Configuration Fields

Address

The Address is used within the overall control system to identify devices. Each device must be given a unique Address to avoid hardware and communication conflicts. The valid value range for assigning an individual device Address is 2-255.

Address

ASCII Port Baud Rate

The ASCII Port Baud Rate configures the baud speed of the NK-SCP/A. The available options from the drop down box are 9600, 14.4k, 28.8k, 38.4k, 57.6k and 115.2k. By default, the baud rate is set to 9600.

ASCII Port Baud Rate

Breakaway Level Map

Breakaway Level Map								
Breakaway num	level mask (L...L+8)							
1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

The Breakaway Level Map is used to configure the router levels to defined breakaways used when switching with the SCP via the ASCII protocol. For ASCII protocol terms and parameters, please refer to “NK-SCP Operation” on page 5–14.

Submit and Upgrade Fields

Submit Settings


The Submit Settings button will upload the settings to the device.

Submit Settings

If users wish to cancel or ignore the settings they have made, click the Online tab to return to the Online Devices page, or click the Refresh button of your browser to revert to the original settings displayed.

Upgrade Firmware

The Upgrade Firmware button is used to upload to the device the latest firmware, contained in a binary file. Upgrading firmware allows new features, enhancements and improvements of the NK-SCP/A to be installed.



NK-SCP/K2 Configuration

The NK-SCP/K2 itself does not need to be configured via the NK-IPS for use, but when connected to the T-Bus Control System it will be displayed on the NK-IPS Online Devices page. The NK routers to be interfaced by the Geneos CPU need to be configured identically in both the router's Device Properties page accessed via the NK-IPS and the Physical Map and Virtual Labels pages in Geneos.

For details on how to configure NK-SCP/K2 via Phoenix, please refer to the *Phoenix Online Help Guide*.

Configuring the Router via the NK-IPS

Each router that is to be accessed by the Geneos CPU, needs to be configured via the NK-IPS. Details on configuring routers can be found in “**Configuring Routers**” on page 4–4.

Configure the router's level, first input and first output on the router's Device Properties page. The values entered here are exactly what are used and stored by the Geneos CPU for control system operation. If multiple routers are being used, each router will have to be configured independently.

- ★ It is recommended that if multiple routers are to be used for switching, that they be configured to have only one level per format.

For details on how to configure NK-SCP/K2 via Phoenix, please refer to the *Phoenix Online Help Guide*.




Figure 4.11 NK-SCP/K2 Device Properties Page

Device Properties Fields

Family

The Family name is set in the factory before shipping and displays the family that the device belongs to. This parameter is read-only.

Family NKseries

Device

The Device name is set in the factory before shipping and displays the name assigned to the device. This parameter is read-only.

Device SCP/K2

Serial Number

The Serial Number is set in the factory before shipping and is unique to each device. This parameter is read-only.

Serial Num 0000015991

Name

The Name field can be assigned by the user to uniquely name a device. This field has a maximum of 16 characters and is used for description and identification only.

Name NK-SCP/K2

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use. This field has a maximum of 16 characters and is used for description and identification only.

Details

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas. This field has a maximum of 10 characters and is used for description and identification only.

Group

Configuration Fields

Address

The Address is used within the overall control system to identify devices. Each device must be given a unique Address to avoid hardware and communication conflicts. The valid value range for assigning an individual device Address is 2-255.

Address 254

Machine Control Enabled

Machine Control Enabled allows reciprocal switching when the check box is checked. By default, Machine Control Enabled is turned off.

Machine Control Enabled ☐

Machine Control Level

The Machine Control Level configures the level that the machine control (if connected) switches reciprocally when switches are performed. The valid range for this field is 1-8 (representing levels).

Machine Control Level 8 (1 to 32)

- ★ If an invalid level (above 8) is entered for the Machine Control Level then the level will default to 8 when the settings are updated to the SCP, regardless of whether the Machine Control Enabled option has been set or not.

First Input/Output

These options allow the Geneos input and output range to be located anywhere within the 16 bit NK Series input/output range. The NK input and output will be offset to start at these values.

First Input 1
First Output 1

Level Position

The level position option allows the user to place the eight Geneos levels within four defined ranges in the 32-level NK Series system. Users can select between:

- 1 -> 8
- 9 -> 16
- 17 -> 24
- 25 -> 32

The NK level will be offset to use this range.

Level Position 1->8 ▼

Startup Delay

The startup delay allows the user to configure a time (in seconds) for the NK-SCP/K2 to wait until the Geneos system is ready before requesting all status.

Startup Delay (s) 5 (5 to 60)

Manual Filter

By default, the NK-SCP/K2 will automatically detect NK-Series routers connected to the T-Bus on startup. With larger routers systems, it is better to manually specify which router output ranges are present.

To use the manual filter:

1. Select the **Manual Filter Enabled** check box
2. For each router **Level**, specify:
 - The **First Output**
 - The number of outputs (**Num. Outputs**)

3. Select the **Enable** check box for each router level in the system.

Manual Filter Enabled ☐

Manual Filter (Kondor)

Level	First Output	Num. Outputs	Enable
1	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
2	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
3	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
4	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
5	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
6	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
7	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>
8	1 (1 to 255)	1 (1 to 255)	<input type="checkbox"/>

Submit and Upgrade Fields

Submit Settings

The Submit Settings button will upload the settings to the device.

Submit Settings

If users wish to cancel or ignore the settings they have made, click the Online tab to return to the Online Devices page, or click the Refresh button of your browser to revert to the original settings displayed.

Upgrade Firmware

The Upgrade Firmware button is used to upload to the device the latest firmware, contained in a binary file. Upgrading firmware allows new features, enhancements and improvements of the NK-SCP/K2 to be installed.

Upgrade Firmware Browse... Submit File

Configuring the Router in Geneos

When each router has been configured from the NK-IPS, the levels, first input and first output must be entered into the Physical Map and Virtual Labels pages in Geneos exactly as they were configured in the router's Device Properties page via the NK-IPS. Configuration of the Virtual Labels page requires that mnemonics be entered from the Mnemonics page.

For more information on configuring levels, inputs and outputs as well as entering mnemonics, refer to the *Geneos User Guide*.

Configuring the GPI

Configuration Options

The NK-GPI Device Properties page, accessible through the NK-IPS, allows users to configure the GPI input and output range, as well as the input and output modes.

For details on how to configure the GPI via Phoenix, please refer to the *Phoenix Online Help Guide*.




Figure 4.12 NK-GPI Device Properties Page

Family

Family NKseries

The Device name is set in the factory before shipping and displays the name assigned to the device. This parameter is read-only.

Device NK-GPI

The Serial Number is set in the factory before shipping and is unique to each device. This parameter is read-only.

Serial Num 0000015991

The Name field can be assigned by the user to uniquely name a device. This field has a maximum of 16 characters and is used for description and identification only.

Name NK - GPI

Details

The Details field can be assigned by the user to give a device specific details. For example, a physical location or a brief description of its use. This field has a maximum of 16 characters and is used for description and identification only.

Details

Group

The Group number can be assigned by the user to organize devices into groups. For example, users can assign separate Group numbers for devices in different physical areas. This field has a maximum of 10 characters and is used for description and identification only.

Group

Configuration Fields

Address

The Address is used within the overall control system to identify devices. Each device must be given a unique Address to avoid hardware and communication conflicts. The valid value range for assigning an individual device Address is 2-255.

Address

GPI Input Table

GPI Ins			
GPI In	Input	Output	Levels (L...L+8)
1	<input type="text" value="1"/>	<input type="text" value="1"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
2	<input type="text" value="2"/>	<input type="text" value="1"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
3	<input type="text" value="2"/>	<input type="text" value="1"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
4	<input type="text" value="4"/>	<input type="text" value="4"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>
5	<input type="text" value="5"/>	<input type="text" value="5"/>	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>

The GPI Input Table (GPI Ins) configures the GPI and crosspoint behavior. When the GPI input is triggered, the specified cross-point is switched.

GPI In Mode

The GPI In Mode configures the GPI input for either Return or Latch mode. Return mode will hold the switch only while the GPI input trigger is held. Latch will switch and hold the crosspoint until another switch is activated.

GPI In Mode: ☐ Return ☒ Latch

GPI Output Table

GPI Outs							
GPI Out	Input	Output	Levels (L...L+8)				
1	1	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2	2	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	3	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	4	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
5	5	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

The GPI Output Table (GPI Outs) configures the GPI output that is triggered when a specified crosspoint is selected.

GPI Out Mode

The GPI Out Mode configures the GPI outputs to either Follow GPI Ins, as configured in the GPI Input Table, or to Use GPI Out Table for crosspoint configuration.

GPI Out Mode: ☐ Follow GPI Ins ☒ Use GPI Out table

Debounce Delay

The Debounce Delay field configures the time (in milliseconds) that the NK-GPI will allow before sending a trigger event.

Debounce delay (ms) 50 (1 to 100)

The NK-GPI does not require a Debounce Delay to be configured when used with other NK Series devices. The field only requires user input if using third party devices.

Panel Link Address

The Panel Link Address is required when users wish to use a panel to select the GPI outputs. When switches are activated by the control panel, the NK-GPI will follow the destinations as chosen by the panel.

Panel Link Address 0

When linking the NK-GPI to a control panel, the Address field must be the same for both devices, whereas the Panel Link Address must be different for each device. By default, the Panel Link Address is set to 0. The valid value range for linking panels is 1-254.

★ Defining an NK-GPI Panel Link Address to follow crosspoint and switch events as selected by an NK control panel will use the panel's destination instead of the destination defined by the GPI Out Mode selection (either in the GPI Input Table or GPI Output Table, depending on the mode selected).

Submit and Upgrade Fields

Submit Settings


The Submit Settings button will upload the settings to the device.

Submit Settings

If users wish to cancel or ignore the settings they have made, click the Online tab to return to the Online Devices page, or click the Refresh button of your browser to revert to the original settings displayed.

Upgrade Firmware

The Upgrade Firmware button is used to upload to the device the latest firmware, contained in a binary file. Upgrading firmware allows new features, enhancements and improvements of the NK-GPI to be installed.

The image shows a web interface for upgrading firmware. It consists of a horizontal bar with a light gray background. On the left, the text "Upgrade Firmware" is displayed in a bold, black font. To the right of this text is a white rectangular input field. Further to the right are two buttons: "Browse..." and "Submit File", both with a light gray background and black text.

Operation

NK Series Operation

Start-up Process

After power has been supplied to the NK Series components, the routers broadcast their status to each other. Panels also listen to these broadcasts and are able to download the matrix status within this time. Linked panels broadcast their internal state (shift, destination, levels, take, chop and machine control). Panels will attempt to retrieve the status for their current output/level pair. Finally panels will request for any protects they may be holding. Any routers (possibly multiple routers) with a protect held by this address will respond.

Router Start-up

On start-up, the newly connected router will attempt to download status from an operating router with the same output range and level. It will then switch all crosspoints and broadcast its status. Routers respond to data messages from other routers to allow this synchronization.

Control Panel Start-up

When a control panel is powered up, the LEDs will light 2 at a time from left to right. It will then fade to a Ross logo, fade that logo out and fade in the current status. This is to allow time for all connected NK devices to synchronize on start up.

Panels remember the last selected output and breakaway/level. These will be restored on power up unless overridden by a linked panel with different values.


Single Panel RCP-NK1 Operation

Overview


The control panel functions detailed below can be programmed with the NK-IPS for full functionality. The examples herein are described using the factory default configuration, loaded with every NK router. For details on the factory configuration, as well as use and features of the NK-IPS, refer to “**Configuration**” on page 4–1.

Key Press/Event Instructions


Please note the following when following the examples in the this section.



A single, thick black border signifying the key indicates a simple key press to execute the action.



Two thin, black lines signifying the key indicates that the key should be held down for approximately 3 seconds and then released to execute to action.



Source and destination keys are labelled as Input and Output keys, in this instance ‘Out11’ signifies Output 11 and ‘In4’ signifies Input 4.



In the example that use the SHIFT key, S SHIFT signifies SOURCE SHIFT and D SHIFT signifies DESTINATION SHIFT. The Input or Output then shown is the desired Input or Output and in brackets underneath the actual key number pressed, as it would be on the default page.

Operation Basics


Destination Keys

Selecting a destination changes the virtual destination the panel controls or switches the next time a SOURCE key is pressed. Destinations can be selected by pressing a preset DESTINATION key

When a preset DESTINATION key is pressed, that key and its source status key (if a preset key exists) will be illuminated. If a breakaway warning occurs, the BREAKAWAY key will flash.

The default configuration for the RCP-NK1 is shown in “**Configuration**” on page 4–1. The bottom, left hand row of 16 keys is set to destination keys 1-16, pressing the DESTINATION SHIFT key will change the bottom row to destination keys 17-32.

Example



Selects preset destination ‘Out11’ as the panel’s controlled destination.


Source Keys

Source switching is performed by pressing a preset SOURCE key. Selecting a source (when a TAKE function key is not assigned) results in the controller requesting the selected source to be switched by the router to the panel’s current destination.

If the switch request was successful the preset SOURCE key is illuminated. If the switch was not successful or generated errors the key will flash several times quickly to indicate that an error has occurred. If a TAKE function key is assigned, the TAKE key will be illuminated and the preset SOURCE key will flash once quickly (this indicates that TAKE is armed). To perform the switch press the TAKE key or press any other key to cancel.

The default configuration for the RCP-NK1 is shown at the start of “**Configuration**” on page 4–1. The top, left hand row of keys is set to source keys 1-16, pressing the SOURCE SHIFT key will change the top row to source keys 17-32.

Example



Switches preset source ‘In5’ to the current destination (if TAKE is not assigned).



Switches preset source ‘In3’ to the current destination (if TAKE is assigned).

Shift Keys

SHIFT keys allow the different pages or sets available to preset SOURCE and DESTINATION keys to be accessed. Up to three different sets of SOURCE and/or DESTINATION keys may be accessed from the panel. The SOURCE SHIFT keys change the current set of SOURCE keys available on the panel and the DESTINATION SHIFT keys change the current set of DESTINATION keys available. All other keys are not affected by SHIFT keys.


When no SHIFT keys are selected, the keys are on the first or default page/set. By pressing a specific SOURCE SHIFT or DESTINATION SHIFT key, the panel immediately changes its relevant sources or destinations to the specified set. The SHIFT key is active when illuminated. Pressing the SHIFT key again, toggles it to the default key set. As the sets change if a SOURCE or DESTINATION key matches the currently controlled destination or the source status that key will be illuminated.

The default configuration for the RCP-NK1 is shown at the start of “**Configuration**” on page 4–1. The top, left hand row of keys is set to source keys 1-16, the bottom, left hand row of keys is set to destination keys 1-16.

Pressing the respective SHIFT key (SOURCE SHIFT or DESTINATION SHIFT) will change the top row to source keys 17-32, and the bottom row to destination keys 17-32.


Example

When selecting a source on the current page (when the SOURCE SHIFT key is not illuminated):



Switches preset source 'In5' to the current destination (if TAKE is not assigned).

When selecting a source on the second page/set:



Switches preset source 'In21' to the current destination (if TAKE is not assigned).

Crosspoint Keys

CROSSPOINT keys perform a preset crosspoint switch in a single key press, and the key will illuminate to indicate the state of that crosspoint. When a crosspoint switch is performed the panel's current destination, source and breakaway (optional) changes to those specified in the CROSSPOINT key assignment. If a breakaway is not specified, the currently selected breakaway on the panel is used for the switch.

If a CROSSPOINT key's preset destination and source status matches that destination's source status in the router on all levels on the current breakaway (or set breakaway) the key will be illuminated. If a TAKE function key is assigned, the TAKE key is illuminated and the preset CROSSPOINT key flashes (this indicates that TAKE is armed).

Example



Switches user defined Xpoint2 (source to destination on breakaway/level), if TAKE is not assigned.




Switches user defined Xpoint5 (source to destination on breakaway/level), if TAKE is assigned.

A CROSSPOINT key is not available on the factory default configuration. For configuration and functionality of the CROSSPOINT key, the NK-IPS is required.

Level Keys

LEVEL keys select the router levels. In the factory default configuration, there are four LEVEL keys assigned to the RCP-NK1. Levels and keys are described below.


Example



Pressing the 'Level2' key will select the SDI level of the router.



Pressing the 'Level5' key will select the Analog Video level of the router.



Pressing the 'Level6' key will select the Left Channel of the Analog Audio level of the router.




Pressing the 'Level7' key will select the Right Channel of the Analog Audio level of the router.

Breakaway Keys

BREAKAWAY keys select preset groups of levels to be controlled. Breakaways can be customized from the control panel's Device Properties page via the NK-IPS. If BREAKAWAY and LEVEL keys are assigned, then the LEVEL keys will reflect the breakaway pattern. When the current breakaway is the first breakaway, the LEVEL keys will not be illuminated. The source status displayed is only for the first level of any given breakaway or level selection.

Example



Pressing the 'Brkway1' key will select the default breakaway as defined in the control panel's Device Properties page via the NK-IPS.



Pressing the 'Brkway2' key will select the custom breakaway as defined in the control panel's Device Properties page via the NK-IPS.

In the factory default configuration of the RCP-NK1, all levels are set to the default breakaway, which is the only defined breakaway.

Breakaway Step Key

When breakaways have been configured from the NK-IPS, a BREAKAWAY STEP key may be used to cycle through the configured breakaways. Pressing this key will change the breakaway to the next breakaway with any levels. The BREAKAWAY STEP key will be illuminated if the current breakaway is not the first breakaway. Holding down the BREAKAWAY STEP key displays the levels enabled in the (current) breakaway pattern.

A BREAKAWAY STEP key is not available on the factory default configuration. For configuration and functionality of the BREAKAWAY STEP key, the NK-IPS is required.

Example



Pressing the 'BrkStep' key will cycle through the breakaways as defined in the control panel's Device Properties page of the NK-IPS.

Macro Keys

Macros can be used to initiate multiple switches in one quick key press. Several MACRO keys can be assigned to one panel and then different macros recorded to each key. When users are required to regularly switch between two or more static switch assignments, macros can be used to switch these in one easy key press.

A macro is an event playback feature similar to a salvo. A salvo will only trigger a series of switches, whereas a macro will record a series of events for express playback at a later time. When the macro is played back, it will activate a sequence of switches to configure the router. Macros can be extremely valuable in minimizing repetitive key presses by configuring multiple switch events (source, destination and crosspoint) to one key.

A macro event comprises a source, destination, crosspoint, macro or protect key press. When appending one macro to another, this is counted as 1 event. This is covered in more detail later under the heading Appending Macros.

A MACRO key can store a maximum of 84 events and users can assign up to 40 MACRO keys on the RCP-NK1 panel. It is recommended that users with only a single, unlinked panel only assign two or three keys as MACRO keys. Users who have several linked panels may find it convenient to have one panel set aside solely for the purpose of macros and assign as many MACRO keys as is required.

Pressing a SHIFT key when recording a macro does not count as an event, as the macro recorder simply recognizes that the key that is actually pressed is the relevant source or destination.

Recording Macros


To record a macro, you first need to start 'macro recording mode'.

1. Hold down the MACRO key for about three seconds. The MACRO key will flash quickly to indicate that the panel has entered macro recording mode.
2. Release the MACRO key. The MACRO key will flash slowly to indicate that the panel is in macro recording mode.
3. Enter the events you wish to record, as you would if you were to activate a switch. Key presses will be acknowledged by a quick flash on the key you have entered into the macro.
4. When you have finished entering switch events, press the MACRO key to exit macro recording mode.

The MACRO key will stop flashing to indicate the panel has exited macro recording mode.

Example 1


To create a macro (Macro1) that sends Input 1 to Outputs 1, 2 and 3, and also sends Input 2 to Outputs 7, 8 and 9 you would follow this sequence of key presses:



Only one MACRO key is available on the factory default configuration. For implementation of additional MACRO keys, the NK-IPS is required.


Example 2

To create a macro (Macro2) that sends Input 1 to Outputs 4, 5, 6 and 7 and also sends Input 2 to Outputs 8 and 9 you would follow this sequence of key presses:



Example 3

To create a macro (Macro3) that sends Input 1 to all Outputs on a 16x16 router, you would follow this sequence:



Follow in this pattern, pressing the next sequential 'Out' number and then 'In1' until you reach the last output desired. In this example, the last desired output is 'Out16'.

Appending Macros

Appending macros is a feature that allows the addition of more events (or another macro) to an already existing macro.

To append a macro, you first need to enter macro recording mode, and then enter macro recording mode again to append the macro.


1. Hold down the MACRO key for about three seconds. The MACRO key will flash quickly to indicate that the panel has entered macro recording mode.
2. Release the MACRO key. The MACRO key will flash slowly to indicate that the panel is in macro recording mode.
3. Hold down the MACRO key again (this will play back the macro internally so that it may be appended). The MACRO key will flash quickly.
4. Release the MACRO key. The MACRO key will again flash slowly to indicate that the panel is in macro recording mode.
5. Enter the events you wish to record as you would if you were to activate a switch. Key presses will be acknowledged by a quick flash on the key you have entered into the macro.
6. When you have finished entering switch events, press the MACRO key to exit macro recording mode.

The MACRO key will stop flashing to indicate the panel has exited macro recording mode.

When appending macros or adding one macro to another, if you use a single input or output in more than one macro, it will override the previous status of that key.

Example

If you wish to add the output status Input 9 to Output 10 to an already existing macro (Macro1 from Example 1 in the previous heading, Recording Macros) you would follow this sequence of key presses:




Adding one Macro to another Macro

Adding one macro to another can be useful when you have more than one macro that shares the same output status (the same source to destination switch assignments) but where one macro also has output status that the other macro has not assigned.

As the macro function is only an event recorder, other macros are stored as one single event, not the sum of the events in that macro. Similarly, if a macro that has already been added to another macro is changed, the appended macro when played back will reflect that change.

Example

If you wish to append Macro1, adding Macro2 to it (from Examples 1 and 2 in the previous heading, Recording Macros) follow this sequence of key presses:



In the example above, the Macros are as follows:

- Macro1 = Input 1 to Outputs 1, 2 and 3, and also sends input 2 to outputs 7, 8 and 9.
- Macro2 = Input 1 to Outputs 4, 5, 6 and 7, and also sends Input 2 to Outputs 8 and 9.

In this example, because Output 7 is used twice, the last status added will be the one used when the macro is played back. The final status of Macro1 when it is played back will be as such will be:

- Input 1 to Outputs 1,2,3,4,5,6 and 7.
- Input 2 to Outputs 8 and 9.

To cancel recording or appending a Macro

To cancel recording or appending a macro, press the macro key after entering macro record mode.

Macros can not be cancelled after entering events in macro recording mode. If a mistake has been made, you will have to exit macro recording mode and enter it again to re-enter events you wish to be played back.

Configuring a Macro Using Phoenix

Macros can be configured in Phoenix using the Macros tab.

1. Assign a macro to a key.
2. Select the **Macros** tab.
3. In the **Num. Rows.** box of the macro, enter or select the number of events to be assigned.
4. Click **Update** to add the events to the **Event** column of the macro.
5. In the **Function** column, use the list to select the function to perform for the event. The options are as follows:
 - **Switch** — performs a standard crosspoint switch.
 - **Macro** — performs a macro within the executed macro.
 - **Protect** — creates a protect condition on the destination of the selected crosspoint (see “**Protect Key**” on page 5–9).
6. In the **Output** column, double-click the **Output** box and enter a destination for the event.
7. In the **Input** column, double-click the **Input** box and enter a source for the event.
8. In the **Level Mask** column, select the level mask or masks for the device or devices affected by the macro.
9. Repeat Steps 5 to 8 for any remaining events of the macro.
10. Send the current document to the device.

For More Information on...

- how to configure RCP-NK1 via Phoenix, refer to the *Phoenix Online Help Guide*.

Configuring a Macro Using a Web Browser

Macros can be configured using a web browser.

1. Assign a macro to a key.
2. Using the **Device Properties** page in the web browser, select **Macros**.
3. In the **Num Rows for Macro** box of the macro, enter the number of events to be assigned.
4. Press **Enter**.

The **Device Properties** page displays a message that the settings were sent to the device.

5. Click the **Online** tab.

The **Online Devices** page opens.

6. Click the **Properties** button for the RCP-NK1.

The **Device Properties** page opens.

7. In the **Device Properties** page, click **Macros**.

The **Device Properties** page displays the **Macro #** tables.

8. In the **Function** column, use the list to select the function to perform for the event. The options are as follows:

- **Switch** — performs a standard crosspoint switch.
- **Macro** — performs a macro within the executed macro.
- **Protect** — creates a protect condition on the destination of the selected crosspoint (see “**Protect Key**” on page 5–9).

9. In the **Output** column, enter a destination for the event.

10. In the **Input** column, enter a source for the event.

11. In the **Level Mask** column, select the level mask or masks for the device affected by the macro.

Each function can occur on any available level, independent of any other function within the same macro event.

12. Repeat Steps 8 to 11 for any remaining events of the macro.

13. Click **Submit Settings** to send the current document to the device.

The **Device Properties** page displays a message that the settings were sent to the device.

For More Information on...

- configuring the RCP-NK1 using a web browser, see “**RCP-NK1 Configuration**” on page 4–14.

Protect Key

The PROTECT key is used to lock current destination from use by other sources, as well as from other linked panels. The PROTECT key is especially useful in instances where destination must be held after a switch has been made.


Panel Lock

A panel may be locked to prevent unwanted key presses (particularly accidental switches). The Panel Lock is reflected on the control panel’s Device Properties page of the NK-IPS, and can be locked or unlocked as required both from the NK-IPS configuration page or from the panel.

To activate the panel lock from the RCP-NK1, follow these steps:

1. Hold down the PROTECT key for about three seconds. The PROTECT key will flash quickly to indicate that the panel lock has been activated.
2. Release the PROTECT key. The PROTECT key will flash slowly to indicate that the panel is locked.

Example



Pressing the PROTECT key will protect the current destination.



Holding the PROTECT key for about 3 seconds will lock the panel.
Holding the key again will unlock the panel.

The PROTECT key’s panel lock function and the PANEL LOCK key are interchangeable. If both function keys are configured on the one panel, a panel lock can be activated from one key, and deactivated from the other.


A PROTECT key is not available on the factory default configuration. For configuration and functionality of the PROTECT key, the NK-IPS is required. A PROTECT key can also be configured on the NK1 panel via Function Key Program Mode.

Take Key

A TAKE function key is used to activate the selected switch. First the required destination is entered, then the required source; the SOURCE key on the panel flashes and the TAKE key illuminates. The switch is activated once

the TAKE key is pressed. The entered crosspoint change will be completed immediately after the TAKE key has been pressed. This enables the user to preset a crosspoint change before the switch is required. The pending switch can be aborted by pressing any key other than the TAKE key.

Example




A TAKE key is not available on the factory default configuration. For configuration and functionality of the TAKE key, the NK-IPS is required. A TAKE key can also be configured on the NK1 panel via Function Key Program Mode.

Chop Key

The CHOP function key enables the user to alternate between two sources. Pressing CHOP will alternate the two previously selected sources for a given destination. Pressing CHOP once will start a slow chop. Pressing CHOP again will increase the speed of the chop to a fast chop and pressing again will discontinue the chop mode. When CHOP is enabled all other keys are disabled.

Example




A CHOP key is not available on the factory default configuration. For configuration and functionality of the CHOP key, the NK-IPS is required. A CHOP key can also be configured on the NK1 panel via Function Key Program Mode.

Deassign Key

The DEASSIGN key parks the current output. It is only available when the Machine Control Enabled option is checked on the router's Device Properties page.

Example



A DEASSIGN key is not available on the factory default configuration. For configuration and functionality of the DEASSIGN key, the NK-IPS is required. A DEASSIGN key can also be configured on the NK1 panel via Function Key Program Mode.

Machine Control Key

The panel may be configured to operate a machine control (RS-422) level. The machine control level will automatically be switched reciprocally for the source (master) and destination (slave) selected. To execute a machine control reciprocal switch, press the MC KEY to enable machine control operation (key will be illuminated) and then press the required destination and source.

Machine control operation is dependent on three settings:

1. Machine Control mode and level options are configured on the control panel's Device Properties page.
2. Machine Control is enabled (using the MC KEY function key).
3. Current breakaway includes the Machine Control level.


An MC KEY does not necessarily have to be assigned to the control panel to enable reciprocal switching. If the Machine Control Enabled option is checked on the control panel's Device Properties page, all switches activated from the panel will be reciprocal.

An MC Key is required to disable machine control reciprocal switching in multiple slave scenarios.

An MC KEY key is not available on the factory default configuration. For configuration and functionality of the MC KEY key, the NK-IPS is required. An MC KEY key can also be configured on the NK1 panel via Function Key Program Mode.

Panel Lock Key

The PANEL LOCK key will lock the panel to prevent unwanted key presses (particularly accidental switches). The PANEL LOCK key can be implemented in environments that do not require a PROTECT key, but do require the ability to lock the panel. The panel lock function is reflected in the control panel's Device Properties page of the NK-IPS, and can be locked or unlocked as required both from the NK-IPS or from the panel itself.



Pressing the PANEL LOCK key will lock the panel. Pressing the key again will unlock the panel.

The PANEL LOCK key and the PROTECT key's panel lock function are interchangeable. If both function keys are configured on the one panel, a panel lock can be activated from one key, and deactivated from the other.

A PANEL LOCK key is not available on the factory default configuration. For configuration and functionality of the PANEL LOCK key, the NK-IPS is required. A PANEL LOCK key can also be configured on the NK1 panel via Function Key Program Mode.

Linked RCP-NK1 Panel Operation

Overview

When panels are linked together, key behavior remains as above (with single panel system), although the following details must be noted when linking panels:

- Pressing CHOP will alternate between two sources, including cases when the sources are on different physical panels.
- Pressing TAKE will activate a take, including cases when the SOURCE key is on a different panel to the TAKE key.
- If any linked panel has a TAKE key, the linked device enters take mode when a source or crosspoint key is pressed.
- Locking one physical panel from the control panel's Device Properties page will also lock all linked panels. The NK-IPS can be used to unlock panels if required.
- Entering macro record mode causes all linked panels to be in macro record mode, switch events and protects can be added from different physical panels.
- Macros cannot be appended or added across panels.

- Page SHIFT keys control source and destination pages for the whole linked panel.
- DESTINATION keys control the destination for the whole panel.
- LEVEL and BREAKAWAY keys control the level mask for the whole panel. Breakaway preview is not available across linked panels.
- If a panel is added to an operating linked panel, the linked panel changes its states in regards to TAKE, PANEL LOCK and cutbus accordingly.
- If a linked panel is added to an operating linked device that is in TAKE, CHOP, PANEL LOCK, or macro recording mode, it starts in that mode.
- Menus do not work across linked panels.

NK-A64 Control Layer

Overview

The Analog Audio level of NK-64 routers offers unparalleled configuration and audio processing, allowing users to mix left and right audio channels to suit their broadcast requirements. Channels may be swapped, phase inverted or converted to mono (both channels left, both channels right, both channels average, sum and difference).




Figure 5.1 NK-A64 Control Layer Block Diagram

Signal processing is conducted by way of a Control Layer. The Control Layer is an additional level within the router matrix that may be mapped to control panel keys to allow users to mix audio channels on the fly. The Control Layer uses SOURCE keys as the triggers to mix the output audio signal. The Control Layer may be used after a source has been switched to a selected destination. **Table 5.1** shows the audio mixing options available for the Control Layer.

Table 5.1 Audio Mixing Options

Input Control	Signal Processing		Description
	Left Channel	Right Channel	
Input 1	L	R	Both channels normal (Default)
Input 2	R	L	Channels swapped
Input 3	L	L	Both channels Left
Input 4	R	R	Both channels Right
Input 5	L	R	Left channel normal, Right channel inverted
Input 6	L	R	Left channel inverted, Right channel normal
Input 7	L+R	L+R	Left channel sum (mono), Right channel sum (mono)
Input 8	L+R	L-R	Left channel sum (mono), Right channel difference

Control Layer Operation via NK Control Panels

The Analog Audio Control Layer can easily be accessed from NK Series control panels. Factory configured systems will allow the NK-A64 Control Layer to operate out of the box. Further configuration of the NK-A64 Control Layer and control panel options requires the NK-IPS.

- ★ Note when assigning breakaways for NK Series control panels, the Control Layer should not be assigned to a breakaway that contains other levels. If users require a breakaway for the NK-A64 Control Layer, it is vital that it is the only level active for that breakaway.

Mixing the Output Audio Signal

When using the Control Layer, users must remember that only the output audio stream is processed within the router matrix, not the input signal. When mixing audio channels, the control layer is selected after the switch has been made, or if the output that requires mixing is already active. Users may record macros to make mixing and switches easier, or if regular audio mixing is required.




Selecting the 'Control Layer' key and then selecting 'In1' will enable the output audio channels to be normal.




Selecting the 'Control Layer' key and then selecting 'In2' will enable the output audio channels to be swapped.



Selecting the 'Control Layer' key and then selecting 'In3' will enable both output audio channels to be the left channel of the source.



Selecting the 'Control Layer' key and then selecting 'In4' will enable both output audio channels to be the right channel of the source.



Selecting the 'Control Layer' key and then selecting 'In5' will enable the left output audio channel to be normal and the right audio channel to be inverted.



Selecting the 'Control Layer' key and then selecting 'In6' will enable the left output audio channel to be inverted and the right audio channel to be normal.




Selecting the 'Control Layer' key and then selecting 'In7' will enable the both output audio channels to be summed.



Selecting the 'Control Layer' key and then selecting 'In' will enable the left output audio channel to be summed and the right audio channel to be differenced.


Example 1

To swap the channels of the output audio signal for 'Out4', first activate a switch by selecting the destination followed by the source and then select the Control Layer, or the breakaway that the Control Layer is on, and lastly select the designated mixing mode.



Example 2

To invert the left channel of the output audio signal for 'Out6', first activate a switch by selecting the destination followed by the source and then select the Control Layer, or the breakaway that the Control Layer is on, and lastly select the designated mixing mode.



- ★ The Control Layer configuration is retained by the destination until the Control Layer is changed. For example, if Input 1 is switched to Output 3 and the left and right channels are swapped (by pressing the Control Layer key and then selecting Input 2) the next Input selected to be switched to Output 3 will also have the left and right channels swapped.

NK-SCP Operation

NK-SCP/A Operation Overview

The NK-SCP/A can be used for control of an entire NK routing system. Switches activated from an external RS-232 device are monitored by all devices on the T-Bus line

The protocol used is a simple ASCII protocol designed to give users a means for simple control of the router via custom PC software or by connecting a terminal to the AUX port and sending ASCII characters.

Using the ASCII Protocol

The protocol used is a simple ASCII protocol designed to give users a means for simple control of the router via custom PC software or by connecting a terminal to the AUX port and sending ASCII characters.

Fixed Parameters

The parameters in **Table 5.2** are fixed.

Table 5.2 COMM Port Fixed Parameters

Parameter	Setting
Parity	None
Stop Bits	1
Data Bits	8
Characters	ASCII

Commands

Table 5.3 describes the protocol commands.

Table 5.3 ASCII Protocol Commands

Command	Description
<X>	Switch an input to an output using a breakaway
<Z>	Switch multiple inputs (one per level) to an output
<R>	Read the current status of an output

Table 5.4 describes the command parameters.

Table 5.4 ASCII Protocol Command Parameters

Command	Description	Value	Note
<ddd>	Destination - output number	(000 to 254)	1
<sss>	Source - input number	(000 to 254)	1
	Breakaway number	(1 to 8)	2
<--->	Blank entry (in place of actual output socket number)		
<CR>	Carriage return character		
<LF>	Line feed character		
<SP>	Space character		

An offset of -1 is required so that the lowest value of 000 points to the router input or output number 1. In this way, inputs and outputs from 1 to 255 can be addressed with dialogue values from 000 to 254.

Switch an input to an output using a defined breakaway

Start the sequence (11 bytes) with an upper case <X> followed by the destination, source, breakaway and carriage return as detailed below. Do not include the parentheses.

<X> <ddd> <,> <sss> <,> <CR>

Response from SCP

- If the data string is valid, the SCP returns response (B).
- If the data string is invalid, the SCP returns response (A).
- If the data string is valid but the source number is unavailable or any of the parameters are incorrectly specified, i.e. greater than 254 (255 to 999) for destination and source and greater than 1 to 8 (0 or 9) for breakaway, the SCP returns response (A) then response (B).

Response (A) <CR> <LF> <ERROR> <CR> <LF>

Response (B) <CR> <LF> <OK> <SP> <CR> <LF>

Switch multiple inputs (one per level) to a output

Start the sequence (37 bytes) with an upper case <Z> followed by the destination, then a source (or <---> to not switch a level) for each of 8 levels and carriage return as detailed below. Do not include the parentheses.

	L1	L2	L3	L4	L5	L6	L7	L8	
<Z>	<ddd>	<, >	<sss,	sss,	sss,	sss,	sss,	sss,	<CR>

Send <---> in place of <sss> to not switch that level.

Response from SCP

- If the data sting is valid, the SCP returns response (B).
- If the data string is invalid, the SCP returns response (A).
- If the data string is valid but the source number is unavailable or any of the parameters are incorrectly specified, i.e. greater than 254 (254 to 999) for destination and source and greater than 1 to 8 (0 or 9) for breakaway, the SCP returns response (A) then response (B).

Response (A) <CR> <LF> <ERROR> <CR> <LF>

Response (B) <CR> <LF> <OK> <SP> <CR> <LF>

Read the current status of a output

Start the sequence (5 bytes) with an upper case <R> followed by the destination and carriage return as detailed below. Do not include the parentheses.

<R> <ddd> <CR>

Response from SCP

- If the data sting is valid, the SCP returns response (C) then (B).
- If the data string is invalid, the SCP returns response (A).
- If the data string is valid but the destination is incorrectly specified, i.e. greater than 254 (255 to 999), the SCP returns response (A) then response (B).

Response (A) <CR> <LF> <ERROR> <CR> <LF>

Response (B) <CR> <LF> <OK> <SP> <CR> <LF>

	L1	L2	L3	L4	L5	L6	L7	L8	
Response (C)	<CR>	<LF>	<sss,	sss,	sss,	sss,	sss,	sss,	<CR> <LF>

NK-SCP/K2 Operation

Implementation of the NK-SCP/K2 means that NK routers can be controlled exactly as if they were a matrix module housed within the Kondor 2 frame. Switches can be activated by Geneos control panels as well as from a Virtual Control Panel (VCP) from the Panelworks page in the Geneos software.

When switches are activated from a control panel or VCP connected to the Geneos CPU, the SCP/K2 monitors commands and converts them to the T-Bus protocol. If the command sent corresponds with a level that an NK router is occupying, then that level will be switched. If there are no NK routers occupying that level, then the switch will be performed where that level is occupied, most likely within the Kondor 2.

Switches can be activated from the NK control panel (RCP-NK1) but are not advised as they will not be reflected within the Geneos CPU status table. If an RCP-NK1 is connected to the router (or T-Bus), any switches activated by the panel will override the status and commands from the Geneos panels or Geneostat virtual control panels.

Video Referencing

Overview

All NK Video and Audio routers are fitted with a video switching reference input to ensure that switching occurs in the vertical interval across all levels. Normally, the reference input signal is a color black (Black burst) composite signal, however it may be any normal composite signal. The NK router will automatically detect the signal as being either 625/50 (PAL) or 525/60 (NTSC) and automatically adjust the switching pulse to comply with RP 168, line 6 for PAL and line 10 for NTSC.

The NK router switches on frame boundaries. There are two 75 Ω BNC reference input BNCs on each NK router arranged as a passive loop-through pair. Normally, a single Black Burst signal is looped through each of the routers which are located together and a 75 Ω terminator is connected to the last BNC socket. An individual Black Burst signal should be wired to routers which are more than a few meters apart.

If the reference signal is absent, the NK router will generate a free-running switching pulse over 40ms. The status of the switching reference may be monitored on the router's Device Properties page via the NK-IPS, one of three conditions may be reported via the NK-IPS: Local, PAL reference present or NTSC reference present.

Connecting a Video Reference to NK Routers

When using a video reference with any of the NK router components, users must remember to terminate the last video reference that is not looped with a 75 Ω BNC terminator.

When only video referencing one router, the other BNC connector of the video reference loop needs to be terminated, as in **Figure 5.2**.




Figure 5.2 Referencing a Single Router

When referencing more than one router, the last reference connector needs to be terminated, as in **Figure 5.3**.




Figure 5.3 Referencing Multiple Routers

Appendix A: Connectors and Pinouts

DB-25 Pinouts for Analog and Digital Audio Routers



The following pinouts are applicable only for current NK-A16, NK-A32, NK-D16/110 and NK-D32/110 routers. These routers can be distinguished by the silk screen of the pinouts on the rear of the router.

Previous routers, without pinouts silk screened on the rear, require an alternate wiring. These are detailed in the **NK Series User Guide v1.0** and v1.1 or in the **NK Series DB-25 Pinouts Application Note**.

The reason for the altered pinouts is that cables can be purchased off the shelf from most audiovisual, broadcast or music retailers.

16x16 Routers

NK-A16 and NK-D32/110

Figure 6.1 shows the pinouts for inputs and outputs on the NK-A16 and NK-D16/110.

The pinouts detailed in **Figure 6.1** are applicable for both left and right channels (NK-A16 only).




Figure 6.1 Pinouts for Inputs and Outputs on the NK-A16 and NK-D16/110

NK-A16 Model Unbalanced Wiring

Input

Figure 6.2 shows pinouts and wiring details for unbalanced input connections (left and right channels) for the NK-A16 model.




Figure 6.2 Input Pinouts

Output

Figure 6.3 shows pinouts and wiring details for unbalanced output connections (left and right channels) for the NK-A16 model.




Figure 6.3 Output Pinouts

32x32 Routers

NK-A32 and NK-D32/110

Figure 6.4 shows the pinouts for both inputs and outputs 17-32 on the NK-A32 and NK-D32/110. Pinouts for inputs and outputs 1-16 are as depicted previously.

The pinouts detailed in **Figure 6.4** are applicable for both left and right channels (NK-A32 only).




Figure 6.4 Pinouts for Inputs and Outputs 17-32 on the NK-A32 and NK-D32/110

NK-A32 Model Unbalanced Wiring

Input

Figure 6.5 shows pinouts and wiring details for unbalanced input connections (left and right channels) for the NK-A32 model.




Figure 6.5 Pinouts for Unbalanced Input Connections for the NK-A32 Model

Output

Figure 6.6 shows pinouts and wiring details for unbalanced output connections (left and right channels) for the NK-A32 model.




Figure 6.6 Pinouts for Unbalanced Output Connections for the NK-A32 Model

64x64 Routers

NK-A64

Figure 6.7 shows the pinouts for both inputs and outputs on the NK-A64. Each connector allows balanced audio of four audio channels, please refer to **Table 7.1** for relative I/O numbers.




Figure 6.7 Pinouts for Inputs and Outputs on the NK-A64

NK-A64 Unbalanced Wiring

Input

Figure 6.8 shows pinouts and wiring details for unbalanced input connections for the NK-A64.




Figure 6.8 Pinouts for Unbalanced Input Connections for the NK-A64

Output

Figure 6.9 shows pinouts and wiring details for unbalanced output connections for the NK-A64.




Figure 6.9 Pinouts for Unbalanced Output Connections for the NK-A64

NK-D64/110

Figure 6.10 shows the pinouts for both inputs and outputs on the NK-D64/110. Pinouts for inputs and outputs 1-32 are as depicted previously.




Figure 6.10 Pinouts for Inputs and Outputs on the NK-D64/110

Power Connector - DB-9 (All NK-16 and NK-32 Routers)

Figure 6.11 shows the DB-9 connector port on the rear of the routers and can be used to connect GPI alarms.




Figure 6.11 DB-9 Connector Port for GPI Alarms

Machine Control DB-9 Pinouts (NK-M16 and NK-M32)

Figure 6.12 shows the pinouts for DB-9 connections on the NK-M16 and NK-M32 Machine Control routers.



The Machine Control DB-9 pinouts are dependent on which mode (Master or Slave) is being used.




Figure 6.12 Pinouts for DB-9 Connections on the NK-M16 and NK-M32 Machine Control Routers

GPI Alarm (NK-64 & NK-72 Models only)

Figure 6.13 shows the 3-way Phoenix connector on the rear of the NK-64 and NK-72 routers which is used to connect GPI alarms.




Figure 6.13 3-way Phoenix Connector for GPI Alarms

T-Bus RJ-45 Connector

Figure 6.14 shows the RJ-45 connector port for the T-Bus control system.




Figure 6.14 RJ-45 Connector port for the T-Bus Control System

SCP/A DB-9 Pinouts

Figure 6.15 shows the DB-9 connector port on the NK-SCP/A.




Figure 6.15 DB-9 Connector Port Pinouts on the NK-SCP/A

SCP/K2 DB-9 Pinouts

Figure 6.16 shows the DB-9 connector port for the NK-SCP/K2.




Figure 6.16 DB-9 Connector Port Pinouts on the NK-SCP/K2

Appendix B: Analog Audio Router I/O Levels

Overview

All NK Series Analog Audio Routers have selectable input and output level control for either +4 or -10 dB audio streams. By default, both input and output levels are set to +4 dB before routers are shipped, unless requested when ordering. Users may change the I/O gain by removing the soldered link on the input or output boards.


Each input or outboard board allows access to 8 channels and level for each audio channel must be set individually. This allows users to have a selection of both +4 dB and -10 dB audio streams connected to each I/O board.

NK-A16 and NK-A32 gain control diagrams have been labelled with I/O connections labelled 1-8; for inputs or outputs above 8, refer to **Table 7.1**.


Table 7.1 Relative Connections for Inputs or Outputs Above 8

Labelled I/O #	Relative I/O #	Relative I/O #	Relative I/O #	Relative I/O #
1	1	9	17	25
2	2	10	18	26
3	3	11	19	27
4	4	12	20	28
5	5	13	21	29
6	6	14	22	30
7	7	15	23	31
8	8	16	24	32


NK-A16 and NK-A32 Routers (Input)




NK-A16 and NK-A32 Routers (Output)



NK-A64 Router (Input)



NK-A64 Router (Output)



Ensure that all four solder connections have been bridged correctly. In cases where only one pair of connections has been soldered correctly and the other pair has been soldered incorrectly, the output audio stream will be unbalanced. Soldering both pairs efficiently will ensure that the output audio stream is balanced.

Appendix C: Multi-Definition Router Format Selection

Output Rise Time DIP Switches

Each individual NK-MD router output features selectable output rise time, dependant.

NK-MD164, NK-MD16, and NK-MD34

DIP switches are located in the middle of the output board.




Figure 8.1 NK-MD164, NK-MD16, & NK-MD34 SD/HD Rise Time DIP Switches (NK-MD34 shown)

DIP switches are labelled on the PCB board and rise time is selected for SD when OFF (in the up position) and HD when ON (in the down position). Each output may be configured individually, if required.

NK-MD64 and NK-MD72

DIP switches are located on each output board's edge, closest to the front of the router frame. Once the router front has been removed, each output may be set individually for either SD or HD operation.




Figure 8.2 NK-MD64 & NK-MD72 SD/HD Rise Time DIP Switches (NK-MD72 shown)

DIP switches are labelled on the PCB board and rise time is selected for SD when OFF (in the up position) and HD when ON (in the down position). Each output may be configured individually, if required.